



SATURN LED Floor Lamp

Assembly Instructions for the Brightech SATURN LED Floor Lamp:

1. Screw bottom pole B onto base A, then pole C onto pole B, pole D onto pole C, and finally, pole E onto pole D. Gently pull excess cord out from the bottom of pole B, making sure it doesn't get caught in the threading.
2. To connect pole-extension heads F and G to pole, apply gentle pressure at connection points until you hear a click. You can customize the level of light by leaving off the pole extension pieces if desired, or connecting just one.
3. Place LED circles I onto slots on poles. They must be placed in the grooved slot to light up when lamp is powered on.
4. Plug power supply H into lamp first, then into outlet, then power on.

Operation and Features:

The Saturn LED Floor Lamp is controlled via a three step foot pedal button built into the power cord. Simply tap the button to turn on and cycle through the dimmer settings. When set into place on the pole, each LED ring will come on at the brightness set for the rest of the lamp. The Saturn can be turned on and off via a wall switch for convenience, but it cannot be dimmed except by cycling through the foot pedal steps. When using the lamp with a wall switch, it will remember its settings: if you turn the switch off with the lamp set to a lower brightness level, it will stay on the same lower level when you turn the switch back on.

Extend Your Warranty, Free :

If you would like to extend your warranty from 3 years to 5, free, fill in this short product registration form on our site :

<https://brightech.com/pages/extended-warranty>.

Thank you!

Thank you for purchasing from Brightech! If you have any trouble whatsoever with your order, please reach out to us via our site, www.brightech.com. We will be happy to assist you.

