
HOMOOI
WISDOM CHOICE



ASSEMBLY INSTRUCTIONS

/ MODEL

W11CC08NN-X W11CC08PL-X
W11CC08QQ-X

IMPORTANT : please read this manual carefully before beginning assembly of this product.keep this manual for future reference.

1

★ **Thank you for choosing our products,please read the instructions carefully before installation,and please keep the instructions properly**

Tips and tricks

1.Do not attempt to move this furniture without first removing all equipment

2.Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over onto the child.

3.Please contact us using the details shown for further advice

⚠ **WARNING** If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!

2

★ **¡Gracias por elegir nuestros productos, por favor lea las instrucciones cuidadosamente antes de la instalación, y guárdelas correctamente!**

Consejos y trucos

1.Si no quita todos los equipos en el primer lugar, no intente mover este mueble

2. Cuando los niños suben a los muebles con el equipo de audio y / o video, la muerte o las lesiones graves podrían ocurrir.El control remoto o los juguetes colocados en el mueble pueden estimar a un niño a subir en el él y el mueble podría volcarse sobre el niño.

3.Póngase en contacto con nosotros utilizando los detalles mostrados para obtener más sugerencias.

⚠ **ADVERTENCIA** Si las piezas faltan o están dañadas, no devuelva el producto dañado a su distribuidor; póngase en contacto con los Servicios al Cliente. ¡Nunca utilice las piezas dañadas!

3

★ **Vielen Dank für Ihre Auswahl für unsere Produkte, lesen Sie bitte die Anweisungen sorgfältig vor Ihrer Installation und halten Sie bitte die Anweisungen richtig!**

Tipps und tricks

1.Versuchen Sie bitte nicht, diese Möbel zu bewegen, ohne zuerst alle Geräte zu entfernen

2.Wenn die Kinder auf Audio und / oder Videogerätemöbel klettern, kann Tod oder schwere Verletzungen kommen. Eine Fernbedienung oder Spielzeug kann die Kinder ermutigen, die auf die Einrichtung gestellt wird, sich auf die Einrichtung zu klettern. Dies bewirkt, dass die Möbel auf Ihre Kinder umfallen könnte.

3.Bitte kontaktieren Sie uns mit den Details für weitere Beratung

⚠ **WARNING** Wenn irgendwelche Teile fehlen oder beschädigt sind, geben Sie bitte den beschädigten Artikel nicht an Ihren Händler zurück; Kontaktieren Sie bitte mit dem Kundendienst. Verwenden Sie bitte niemals beschädigte Teile!

4

★ **弊社の製品を選んでくれてありがとうございます。インストールする前に説明書をご覧にいただき、それに当説明書を適切に保存してください。**

提示と技巧

1.設備を全て開かない場合、当設備を移動することはできません。

2.子どもがステレオまたはビデオの設備の上に登ると、体を壊したり、ひどく傷ついたりする恐れがある。設備のリモコンと玩具によって、子ども が設備の上に登りたがっているかも知れないので、設備は子どもの身にに倒れる危険がある。

3.設備の使用に関わる詳細な情報を弊社にご連絡してください。

⚠**警告** どんな部品が紛失したり壊れたりする場合でも、そのままディーラーのところへ返送しないでくだい、顧客サービスセンターに連絡してください。壊れた部品を使用しないてください。

5

★ **Nous vous remercions d'avoir sélectionné nos produits, lisez les instructions attentivement avant l'installation, et gardez les instructions correctement s'il vous plaît!**

Conseils et astuces

1.Ne tentez pas de déplacer ce mobilier sans enlever tout l'équipement.

2. Des dégâts ou des blessures graves pourraient survenir lorsque les enfants grimpent sur des meubles audio et / ou vidéo. Une télécommande ou des jouets places sur le meuble pourraient encourager un enfant à grimper sur le meuble, il en résulte que le meuble pourrait basculer sur l'enfant.

3.Contactez-nous en utilisant les détails affichés pour obtenir les conseils s'il vous plaît

⚠ **AVERTISSEMENT** S'ily a des pièces manquantes ou endommagées, ne renvoyez pas l'article endommagé à votre vendeur; Contactez le service clientèle. Ne jamais utiliser de pièces endommagées!

6

★ **Grazie per aver scelto i nostri prodotti, si prega di leggere attentamente le istruzioni prima dell'installazione e rispettare le istruzioni corrette!**

Suggerimenti e trucchi

1.Non tentare di spostare questo mobile senza prima rimuovere tutte le apparecchiature

2. Possono verificarsi morti o gravi lesioni quando i bambini salgono su mobili per arredamento audio e/o video. Un telecomando o i giocattoli messi sull'arredamento possono incoraggiare un bambino ad arrampicarsi sull'arredamento, e di conseguenza l'arredamento può piegarsi sul bambino.


3.Vi preghiamo di contattarci utilizzando i dettagli mostrati per ulteriori consigli

⚠ **AVVERTENZA:** Sse mancano o sono danneggiate parti, non restituire l'elemento danneggiato al rivenditore; Contattare il Servizio Clienti. Non utilizzare mai parti danneggiate!









Free replacement of damage

Support @ s-wampat.com

WHAT'S IN THE BOX





WHAT'S IN THE BOX


A x 41  Cam bolt Ø6x34mm	**B** x 23  Wooden dowel Ø8x30mm	**C** x 41  Cam lock Ø15x9mm	**D** x 18  Screw Ø4x38mm	**E** x 4  Screw Ø4x25mm
F x 4  Screw Ø4x15mm	**G** x 9  Screw Ø3.5x12mm	**H** x 3  Tip ON	**I** x 3  Washer	
J x 1  a b c d e Tipping restraint hardware kit (inside plastic bag)				
 Tools Required (Not included)				


1


INSTALLATION STEPS
















· Screw cam bolts (A) into panel (1), panel (2), panel (3) and panel (4).




2

INSTALLATION STEPS





· Assemble the Metal bar (7) to panel (1) with Screws (E).
· Assemble the Tip ON (H) to panel (1) and Two panel (6) with Screws (G).



3


INSTALLATION STEPS






· Insert dowels (B) into panel (5).
· Attach panel (5) to panel (5) correctly.





· Insert dowels (B) into panel (5).
· Attach panel (1) to panel (5) correctly.






· Insert and secure cam locks (C) to panel (5) to lock it.





· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.




4

INSTALLATION STEPS






· Insert dowels (B) into panel (5).
· Attach panel (4) to panel (5) correctly.



· Insert and secure cam locks (C) to panel (5) to lock it.





· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.




5


INSTALLATION STEPS








· Insert dowels (B) into panel (1), panel (4) and Two panel (5).
· Attach panel (2) to panel (1), panel (4) and Two panel (5) correctly.



· Insert and secure cam locks (C) to panel (1), panel (4) and Two panel (5) to lock it.





· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.



6

INSTALLATION STEPS






· Insert dowels (B) into Two panel (6).
· Attach Two panel (6) to panel (2) correctly.
· Insert and secure cam locks (C) to Two panel (6) to lock it.





· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.




7

INSTALLATION STEPS








· Insert dowels (B) into panel (1), panel (4), Two panel (5) and Two panel (6).
· Attach panel (3) to panel (1), panel (4), Two panel (5) and Two panel (6) correctly.

· Insert and secure cam locks (C) to panel (1), panel (4), Two panel (5) and Two panel (6) to lock it.
· Assemble Metal bar (7) to panel (2) and panel (3) with Screws (F).




· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.




8

INSTALLATION STEPS




· Screw cam bolts (A) into panel (13), panel (14) and panel (15).
· Assemble Washer (I) into panel (13), panel (14) and panel (15) with Screws (G).




9

INSTALLATION STEPS

· Attach panel (8), panel (9) and panel (11) to panel (10) with Screws (D).






· Carefully slide panel (12) into place along the bottom of the assembly.



10

INSTALLATION STEPS




· Attach panel (13), panel (14), panel (15) to panel (8), panel (9) and panel (11).
· Insert and secure cam locks (C) to panel (8), panel (9), panel (11) to lock it.

C x 15




11


INSTALLATION STEPS



Adjust suitable length, complete the installation.



Please note that the drawers must be installed as indicated by the arrows.




12

INSTALLATION STEPS

WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



1	2	3

Dear customer:

Thanks for your purchase in our store.

Any questions, please contact us via Support @ s-wampat.com with below details:

1. Purchase platform & order number

2.Model number & Instruction version#

3. The detailed photo (faulty part, damage part, if some parts are missing,


please circle it/them on the manual instruction) and send to us.

HOMOOI

WISDOM CHOICE

We'll reply as soon as we receive your message (usually within 24 hours).

HOMOOI
WISDOM CHOICE



ASSEMBLY INSTRUCTIONS

/ MODEL

W07CC08GN-X W07CC08HL-X
W07CC08JQ-X

IMPORTANT : please read this manual carefully before beginning assembly of this product.keep this manual for future reference.

1

★ **Thank you for choosing our products,please read the instructions carefully before installation,and please keep the instructions properly**

Tips and tricks

1.Do not attempt to move this furniture without first removing all equipment

2.Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over onto the child.

3.Please contact us using the details shown for further advice

⚠ **WARNING** If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!

2

★ **¡Gracias por elegir nuestros productos, por favor lea las instrucciones cuidadosamente antes de la instalación, y guárdelas correctamente!**

Consejos y trucos

1.Si no quita todos los equipos en el primer lugar, no intente mover este mueble

2. Cuando los niños suben a los muebles con el equipo de audio y / o video, la muerte o las lesiones graves podrían ocurrir.El control remoto o los juguetes colocados en el mueble pueden estimar a un niño a subir en el él y el mueble podría volcarse sobre el niño.

3.Póngase en contacto con nosotros utilizando los detalles mostrados para obtener más sugerencias.

⚠ **ADVERTENCIA** Si las piezas faltan o están dañadas, no devuelva el producto dañado a su distribuidor; póngase en contacto con los Servicios al Cliente. ¡Nunca utilice las piezas dañadas!

3

★ **Vielen Dank für Ihre Auswahl für unsere Produkte, lesen Sie bitte die Anweisungen sorgfältig vor Ihrer Installation und halten Sie bitte die Anweisungen richtig!**

Tipps und tricks

1.Versuchen Sie bitte nicht, diese Möbel zu bewegen, ohne zuerst alle Geräte zu entfernen

2.Wenn die Kinder auf Audio und / oder Videogerätemöbel klettern, kann Tod oder schwere Verletzungen kommen. Eine Fernbedienung oder Spielzeug kann die Kinder ermutigen, die auf die Einrichtung gestellt wird, sich auf die Einrichtung zu klettern. Dies bewirkt, dass die Möbel auf Ihre Kinder umfallen könnte.

3.Bitte kontaktieren Sie uns mit den Details für weitere Beratung

⚠ **WARNING** Wenn irgendwelche Teile fehlen oder beschädigt sind, geben Sie bitte den beschädigten Artikel nicht an Ihren Händler zurück; Kontaktieren Sie bitte mit dem Kundendienst. Verwenden Sie bitte niemals beschädigte Teile!

4

★ **弊社の製品を選んでくれてありがとうございます。インストールする前に説明書をご覧にいただき、それに当説明書を適切に保存してください。**

提示と技巧

1.設備を全て開かない場合、当設備を移動することはできません。

2.子どもがステレオまたはビデオの設備の上に登ると、体を壊したり、ひどく傷ついたりする恐れがある。設備のリモコンと玩具によって、子ども が設備の上に登りたがっているかも知れないので、設備は子どもの身にに倒れる危険がある。

3.設備の使用に関わる詳細な情報を弊社にご連絡してください。

⚠**警告** どんな部品が紛失したり壊れたりする場合でも、そのままディーラーのところへ返送しないでくだい、顧客サービスセンターに連絡してください。壊れた部品を使用しないてください。

5

★ **Nous vous remercions d'avoir sélectionné nos produits, lisez les instructions attentivement avant l'installation, et gardez les instructions correctement s'il vous plaît!**

Conseils et astuces

1.Ne tentez pas de déplacer ce mobilier sans enlever tout l'équipement.

2. Des dégâts ou des blessures graves pourraient survenir lorsque les enfants grimpent sur des meubles audio et / ou vidéo. Une télécommande ou des jouets places sur le meuble pourraient encourager un enfant à grimper sur le meuble, il en résulte que le meuble pourrait basculer sur l'enfant.

3.Contactez-nous en utilisant les détails affichés pour obtenir les conseils s'il vous plaît

⚠ **AVERTISSEMENT** S'ily a des pièces manquantes ou endommagées, ne renvoyez pas l'article endommagé à votre vendeur; Contactez le service clientèle. Ne jamais utiliser de pièces endommagées!

6

★ **Grazie per aver scelto i nostri prodotti, si prega di leggere attentamente le istruzioni prima dell'installazione e rispettare le istruzioni corrette!**

Suggerimenti e trucchi


1.Non tentare di spostare questo mobile senza prima rimuovere tutte le apparecchiature

2. Possono verificarsi morti o gravi lesioni quando i bambini salgono su mobili per arredamento audio e/o video. Un telecomando o i giocattoli messi sull'arredamento possono incoraggiare un bambino ad arrampicarsi sull'arredamento, e di conseguenza l'arredamento può piegarsi sul bambino.










3.Vi preghiamo di contattarci utilizzando i dettagli mostrati per ulteriori consigli


⚠ **AVVERTENZA:** Sse mancano o sono danneggiate parti, non restituire l'elemento danneggiato al rivenditore; Contattare il Servizio Clienti. Non utilizzare mai parti danneggiate!

WHAT'S IN THE BOX



WHAT'S IN THE BOX


A x 12  Cam bolt Ø6x34mm	**B** x 12  Wooden dowel Ø8x30mm	**C** x 12  Cam lock Ø15x9mm	**D** x 8  Plastic wedge	**E** x 8  Screw Ø3x17mm
F x 24  Screw Ø3.5x14mm	**G** x 6  Screw Ø3.5x12mm	**H** x 2  Tip ON	**I** x 2  Washer	**J** x 4  Hinge
K x 4  Shelf Support	**L** x 1  a b c d e Tipping restraint hardware kit (inside plastic bag)			




Tools Required
(Not included)

1

INSTALLATION STEPS




· Screw cam bolts (A) into panel (1), panel (3) and panel (4).




2

INSTALLATION STEPS




· Assemble the Tip ON (H) to panel (1) with Screws (G).





3

INSTALLATION STEPS




· Insert dowels (B) into panel (2).
· Attach panel (2) to panel (1) correctly.
· Insert and secure cam locks (C) to panel (2) to lock it.






4

INSTALLATION STEPS






· Insert dowels (B) into panel (1), panel (2) and panel (5).
· Attach panel (1), panel (2) and panel (5) to panel (3) correctly.
· Insert and secure cam locks (C) to panel (1), panel (2) and panel (5) to lock it.




· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.



5


INSTALLATION STEPS


· Carefully slide panel (7) into place along the panel (3) of the assembly.



6

INSTALLATION STEPS






· Insert dowels (B) into panel (1), panel (2) and panel (5).
· Attach panel (4) to panel (1), panel (2) and panel (5) correctly.
· Insert and secure cam locks (C) to panel (1), panel (2) and panel (5) to lock it.




· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.




7

INSTALLATION STEPS




· Input panel (6) to the stand with Shelt Support (K).



8


INSTALLATION STEPS





· Assemble the Hinge (J) to panel (8) and panel (9) with Screws (F).
· Assemble the Washer (I) to panel (8) and panel (9) with Screws (G).

J x 4	F x 8	G x 2	I x 2
			

9 INSTALLATION STEPS








Adjust suitable length, complete the installation.

· Input panel (8) and panel (9) to the stand with Screws (F).




· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.




10

INSTALLATION STEPS





· Secure parts (D) to panel (1), panel (3), panel (4) and panel (5) using screws (E).



11


INSTALLATION STEPS






· To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which mean and you can adjust up or down by a few mm.
Then tighten back up.



· To adjust depth.

Loosen screw"B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again.
Tighten screw "B" and "C".



· To adjust side ways.


Turning the screw "C" on BOTH hinges on each door.

12

INSTALLATION STEPS

WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



1	2	3

Dear customer:

Thanks for your purchase in our store.

Any questions, please contact us via Support @ s-wampat.com with below details:

1. Purchase platform & order number

2.Model number & Instruction version#

3. The detailed photo (faulty part, damage part, if some parts are missing,

please circle it/them on the manual instruction) and send to us.


HOMOOI

WISDOM CHOICE

24h

We'll reply as soon as we receive your message (usually within 24 hours).

HOMOOI
WISDOM CHOICE



ASSEMBLY INSTRUCTIONS

/ MODEL

W08CC08AN-X W08CC08BL-X
W08CC08CQ-X

IMPORTANT : please read this manual carefully before beginning assembly of this product.keep this manual for future reference.

1

★ **Thank you for choosing our products,please read the instructions carefully before installation,and please keep the instructions properly**

Tips and tricks

1.Do not attempt to move this furniture without first removing all equipment

2.Death or serious injury may occur when children climb on audio and/or video equipment furniture. A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over onto the child.

3.Please contact us using the details shown for further advice

⚠ **WARNING** If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!

2

★ **¡Gracias por elegir nuestros productos, por favor lea las instrucciones cuidadosamente antes de la instalación, y guárdelas correctamente!**

Consejos y trucos

1.Si no quita todos los equipos en el primer lugar, no intente mover este mueble

2. Cuando los niños suben a los muebles con el equipo de audio y / o video, la muerte o las lesiones graves podrían ocurrir.El control remoto o los juguetes colocados en el mueble pueden estimar a un niño a subir en el él y el mueble podría volcarse sobre el niño.

3.Póngase en contacto con nosotros utilizando los detalles mostrados para obtener más sugerencias.

⚠ **ADVERTENCIA** Si las piezas faltan o están dañadas, no devuelva el producto dañado a su distribuidor; póngase en contacto con los Servicios al Cliente. ¡Nunca utilice las piezas dañadas!

3

★ **Vielen Dank für Ihre Auswahl für unsere Produkte, lesen Sie bitte die Anweisungen sorgfältig vor Ihrer Installation und halten Sie bitte die Anweisungen richtig!**

Tipps und tricks

1.Versuchen Sie bitte nicht, diese Möbel zu bewegen, ohne zuerst alle Geräte zu entfernen

2.Wenn die Kinder auf Audio und / oder Videogerätemöbel klettern, kann Tod oder schwere Verletzungen kommen. Eine Fernbedienung oder Spielzeug kann die Kinder ermutigen, die auf die Einrichtung gestellt wird, sich auf die Einrichtung zu klettern. Dies bewirkt, dass die Möbel auf Ihre Kinder umfallen könnte.

3.Bitte kontaktieren Sie uns mit den Details für weitere Beratung

⚠ **WARNING** Wenn irgendwelche Teile fehlen oder beschädigt sind, geben Sie bitte den beschädigten Artikel nicht an Ihren Händler zurück; Kontaktieren Sie bitte mit dem Kundendienst. Verwenden Sie bitte niemals beschädigte Teile!

4

★ **弊社の製品を選んでくれてありがとうございます。インストールする前に説明書をご覧にいただき、それに当説明書を適切に保存してください。**

提示と技巧

1.設備を全て開かない場合、当設備を移動することはできません。

2.子どもがステレオまたはビデオの設備の上に登ると、体を壊したり、ひどく傷ついたりする恐れがある。設備のリモコンと玩具によって、子ども が設備の上に登りたがっているかも知れないので、設備は子どもの身にに倒れる危険がある。

3.設備の使用に関わる詳細な情報を弊社にご連絡してください。

⚠**警告** どんな部品が紛失したり壊れたりする場合でも、そのままディーラーのところへ返送しないでくだい、顧客サービスセンターに連絡してください。壊れた部品を使用しないてください。

5

★ **Nous vous remercions d'avoir sélectionné nos produits, lisez les instructions attentivement avant l'installation, et gardez les instructions correctement s'il vous plaît!**

Conseils et astuces

1.Ne tentez pas de déplacer ce mobilier sans enlever tout l'équipement.

2. Des dégâts ou des blessures graves pourraient survenir lorsque les enfants grimpent sur des meubles audio et / ou vidéo. Une télécommande ou des jouets places sur le meuble pourraient encourager un enfant à grimper sur le meuble, il en résulte que le meuble pourrait basculer sur l'enfant.

3.Contactez-nous en utilisant les détails affichés pour obtenir les conseils s'il vous plaît

⚠ **AVERTISSEMENT** S'ily a des pièces manquantes ou endommagées, ne renvoyez pas l'article endommagé à votre vendeur; Contactez le service clientèle. Ne jamais utiliser de pièces endommagées!

6

★ **Grazie per aver scelto i nostri prodotti, si prega di leggere attentamente le istruzioni prima dell'installazione e rispettare le istruzioni corrette!**

Suggerimenti e trucchi

1.Non tentare di spostare questo mobile senza prima rimuovere tutte le apparecchiature

2. Possono verificarsi morti o gravi lesioni quando i bambini salgono su mobili per arredamento audio e/o video. Un telecomando o i giocattoli messi sull'arredamento possono incoraggiare un bambino ad arrampicarsi sull'arredamento, e di conseguenza l'arredamento può piegarsi sul bambino.


3.Vi preghiamo di contattarci utilizzando i dettagli mostrati per ulteriori consigli

⚠ **AVVERTENZA:** Sse mancano o sono danneggiate parti, non restituire l'elemento danneggiato al rivenditore; Contattare il Servizio Clienti. Non utilizzare mai parti danneggiate!







Free replacement of damage

Support @ s-wampat.com

WHAT'S IN THE BOX



WHAT'S IN THE BOX


A x 14  Cam bolt Ø6x34mm	**B** x 14  Wooden dowel Ø8x30mm	**C** x 14  Cam lock Ø15x9mm	**D** x 10  Plastic wedge	**E** x 10  Screw Ø3x17mm
F x 8  Screw Ø3x14mm	**G** x 8  Screw Ø3.5x12mm	**H** x 2  Metal Plate	**I** x 2  Angle Bracket	**J** x 14  Sticker

K x 2



a **b** **c** **d** **e**


Tipping restraint hardware kit
(inside plastic bag)




Tools Required
(Not included)

1

INSTALLATION STEPS





· Screw cam bolts (A) into panel (1) and panel (2).



2

INSTALLATION STEPS






· Insert dowels (B) into panel (3) and two panel (4).
· Attach panel (3) and two panel (4) to panel (1) correctly.
· Insert and secure cam locks (C) to panel (3) and two panel (4) to lock it.





· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.




3

INSTALLATION STEPS






· Insert dowels (B) into panel (5).
· Attach panel (5) to panel (1) correctly.
· Insert and secure cam locks (C) to panel (5) to lock it.



4

INSTALLATION STEPS

· Carefully slide panel (6) and panel (7) into place along the panel (1) of the assembly.





2 Person Task

· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.

5

INSTALLATION STEPS





· Insert dowels (B) into panel (3), two panel (4) and panel (5).
· Attach panel (2) to panel (3), two panel (4) and panel (5) correctly.
· Insert and secure cam locks (C) to panel (3), two panel (4) and panel (5) to lock it.




· Due to the screw not being tightened, it is recommended that personnel assist to stabilize the product.


B x 7	C x 7
	

6

INSTALLATION STEPS




· Attach panel (6) and panel (7) to two panels (4) using screws (F).




7


INSTALLATION STEPS




· Secure parts (D) to panel (1), panel (2), panel (3) and panel (5) using screws (E).





8 INSTALLATION STEPS







Please align the cabinets before securing them with screws to avoid cabinet misalignment after installation.





· Secure panel with screws (G), Metal plate (H) and Angle braket (I) as per diagram.

· You can use this product with other products from the same series shown in the picture.
· Please refer to the following steps for installation methods.


G x 8	H x 2	I x 2
		


9

INSTALLATION STEPS


WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.











Stick stickers (J) on cam locks (C).

1	2	3





Dear customer:

Thanks for your purchase in our store.

Any questions, please contact us via Support @ s-wampat.com with below details:

1. Purchase platform & order number

2.Model number & Instruction version#

3. The detailed photo (faulty part, damage part, if some parts are missing,

please circle it/them on the manual instruction) and send to us.

HOMOOI

WISDOM CHOICE

24h

We'll reply as soon as we receive your message (usually within 24 hours).