

印刷说明：
尺寸：展开为380*210mm
每折为95*210mm
材质：128g铜版纸
装订：风琴折页



FLOOR LAMP
USER MANUAL



US Attention: Read Carefully the matters listed below

1. Please screw up connection poles tightly for sturdiness.
2. Applicable bulb types: LED Bulb / Incandescent Bulb / CFL Bulb / Smart Bulb / RGB Changing Bulb.
3. Bulb Base: E26.
4. Specified voltage should be AC110V.

UK/AU Attention: Read Carefully the matters listed below

1. Please screw up connection poles tightly for sturdiness.
2. Applicable bulb types: LED Bulb / Incandescent Bulb / CFL Bulb / Smart Bulb / RGB Changing Bulb.
3. Bulb Base: E27.
4. Specified voltage should be AC220V-240V.

DE Achtung! Lesen Sie sorgfältig die unten aufgeführten Punkte

1. bitte schrauben Sie die Verbindungsstangen fest, um die Stabilität zu gewährleisten.
2. verwendbare Glühbirnen-Typen: LED-Glühbirne / Glühbirne / CFL-Glühbirne / Smart-Glühbirne / RGB-Wechsel-Glühbirne.
3. glühbirne Socket: E27.
4. die angegebene Spannung sollte AC220V sein.

FR Attention : Lisez attentivement les points suivants

1. visser fermement les pôles de connexion pour assurer la solidité de l'appareil.
2. les types d'ampoules applicables : Ampoule LED / Ampoule incandescente / Ampoule CFL / Ampoule intelligente / Ampoule changeante RGB.
3. Base de l'ampoule : E27.
4. la tension spécifiée doit être AC220V.

IT Attenzione: Leggere attentamente i punti elencati di seguito


1. Avvitare bene i poli di collegamento per garantire la robustezza.
2. Tipi di lampadine applicabili: Lampadina LED / lampadina a incandescenza / lampadina CFL / lampadina intelligente / lampadina RGB.
3. Base della lampadina: E27.
4. La tensione specificata dovrebbe essere AC220V.

ES Atención: Lea atentamente los siguientes puntos

1. Por favor, atornille los polos de conexión firmemente para mayor robustez.
2. Tipos de bombillas aplicables: Bombilla LED / Bombilla incandescente / Bombilla CFL / Bombilla inteligente / Bombilla RGB cambiante.
3. Base de la bombilla: E27.
4. El voltaje especificado debe ser AC220V.

JP 注意下記の事項をよくお読みください

1. 接続ポールは適文にネジ止めしてください
2. 適合電球 LED電球/白熱電球/CFL電球/スマート電球/RGB変更電球
3. 電球口金: E26.
4. Specified 電圧は AC100V べきです



A+B+C+E+F+G+H+I+M

NO.	TYPE	QTY
D		6PCS
J		3PCS
K		10PCS
L		1PCS
N		2PCS
O		1PCS
P		1PCS
Q		1PCS
LAMP SHADE		
NO.	TYPE	QTY
a		1PCS
b		6PCS
c		1PCS
d		1PCS
e		1PCS

Step 1

- Assemble the saddle (A) to the tripod (B), then pull the cord through the tripod (B).
- Assemble the pole (C) and (D) to the tripod (B), then tighten the cord at the end of the pole (C).

Step 2

- Assemble pole(C) and pole(D) into the holes next to the board(E), and then tighten pole(F) and pole(D) to secure the board.

Step 3

- Assemble pole(F) and pole(D) into the holes next to the board(G) and tighten pole(H) and pole(D) to secure board.

Step 4




- Assemble the metal plate (J) to the wooden board (I) with screws (K), and tighten it with the wrench (J). Assemble pole(H) and pole(D) into the holes next to the board(I), and then tighten pole(M) and pole(N) to secure the board. And then please adjust the length of the cord through pole (M) to make it fit better.

Step 5

- Take the folded fabric shade (P2) and frames (P1, P3) out of the package.
- Assemble the tube(b) to the frame(a), then insert the frame (c) into the tube(b).
- The frame(P3) can be assembled in the same way as the frame(P1). Then fix frames (P1) and (P3) into the lampshade (P2).

Step 6

- Assemble the harp(O) into the saddle(A), and then unscrew the finial(Q) from the harp(O). Put the assembled lampshade(P) on, and then tighten the finial(Q) to complete the assembly.



Install the shade frame by Accessories