

## OPERATION

**IMPORTANT:** If you have two or more fans, please follow steps below to control each fan independently. Also follow steps below to re-pair the remote and the receiver when needed.

Install battery (included). To prevent damage to transmitter, remove the battery if not used for long periods of time.

**1. 1-6 buttons:**

These six buttons are used to set the fan speed as follows  
1 = minimum speed  
6 = maximum speed

**2.  button:**

This button is used to turn on the fan

**3.  button:**

This button sets fan direction forward or reverse.

**4.  button:**

This button controls the "on/off" status of the light.  
Light bulb type:E26 Bulb\*4(Bulbs not Included)

**5.  button:**

Press and hold this button within 5 seconds of turning on the power to pair. In the case of successful pairing, pressing once controls the fan on/off status

**6. ON button:**


This button is used to turn on the fan and lights

**7. OFF button:**

This button is used to turn off the fan and lights

**8. 1h,2h,4h and 8h buttons:**

These four buttons are used to set the fan timer as follow:  
1h= 1 hour timer  
2h=2 hour timer  
4h=4 hour timer  
8h=8 hour timer



If the pairing is successful, the fan's lighting kit will flash for 3 seconds and then the lights will remain on

**NOTE:** If the self calibration test failed, turn the AC power off; restore power and process the self calibration test again.