

DREAMSIDEA

INSTRUCTION MANUAL



NO:2001




DREAMSIDEA

Tel.+1-562-510-9089

E-mail:support@dreamsidea.com

<https://www.dreamsidea.com>

EXPLODED VIEW




PARTS

A*1



Finial

B*1



Shade

C*1




lampshade
holder

D*1

Light
socket

E*1


Body



Body

STEP 1


Take out all parts from the box.



A*1



B*1




C*1



D*1

E*1



ATTENTION

Please inspect the wires before installation, if the wires show any cut or abrasion, or has exposed copper wires,

DO NOT use the fixture, it might be caused during transportation or defect product.


Before starting installation of the fixture, please remove the previous fixture (if any). Disconnect the power by turning off the electric break for your property (Please ask for professional help if needed).

MAINTENANCE AND WARNING

- Verify the lamp model suits the environment (indoor/outdoor, IP rating) and check all accessories (body, screws, cord, manual).
- Only use with bulbs of the recommended type and wattage. Exceeding the maximum wattage may cause overheating or fire.
- Do not install the fixture if any part is damaged or missing.
- The fixture may become hot during use. Allow to cool before handling.
- Clean dust accumulation in recessed lamps regularly (to prevent overheating), but only when powered off; never rinse with water.
- If the fixture includes a dimmer switch, ensure it is compatible with the fixture before installation.
- Do not modify the fixture in any way; tampering with electrical components can result in malfunction or risk of fire.


STEP 2

Twist the light socket (D) onto the body (E) as shown.




STEP 3

Place the lampshade holder (C) into the designated slots of the light socket as shown. Remember to apply some force to make sure both tips are correctly placed in the slots.




STEP 4

Place the lampshade holder (C) into the designated slots of the light socket as shown. Remember to apply some force to make sure both tips are correctly placed in the slots.




STEP 5

If the lamp shade is tilted, you can simply adjust the position by holding the lamp holder as shown, and gently move the lampholder to make it upstraight.




STEP 6

If the lamp shade is tilted, you can simply adjust the position by holding the lamp holder as shown, and gently move the lampholder to make it upstraight.



STEP 7

Place the lampshade (B) onto the top bolt part of the lampshade holder as shown, and twist the finial (A) to fix the lampshade.



STEP 8

Place the lampshade (B) onto the top bolt part of the lampshade holder as shown, and twist the finial (A) to fix the lampshade.

