


MODEL# ZFFM-0788

Furnimart™

Swivel Curved Sofa




ASSEMBLY INSTRUCTION

The Mart we Serve, The Art you Love

With decades of cooperation with global renowned brands such as Ashley, Walmart, etc, we know the importance of laying stress on products, especially on design, research & development and quality.

Based on the creative vision under the theme of art, nature and elegance, Furnimart sailed the journey which aims at making each item refined and exquisite, turning each piece of furniture into a true work of art.

We are eager to satisfy every customer from different cultural and custom background with unique elegance and craftsmanship.



Brand Philosophy

Creativity knows no boundary.

Quality is of ultimate importance.

Mission & Value

We are passionate to create new styles and bring you an unforgettable furniture experience.













Company Introduction

We have been running our own overseas factories for more than 10 years, the cooperation with world-class furniture companies enables us to establish our team in the USA, Europe and Asia, they are not only persistent to tap the potential market, but also attach great importance to the latest trend and vogue in the industry.


Our factories have been audited by many well-known brands.



Assembly Instruction


Ax1  Backrest	Bx1  Chair base	C-Lx1  Left armrest	C-Rx1  Right armrest
Dx2  Left and right ears	Ex1  Backrest iron frame	Fx1  Seat cushion metal frame	Gx2  Straight plug blade
Hx4  Slanted insert piece	Jx1  Mobile phone stand claws	Kx1  Mobile phone stand rod	Lx1  Connection line
Mx1  Power plug	Nx1  Power cord	Ox1  Wrench	Px1  M5
Qx8  M6*20mm	Rx4  M6*16mm		

1




First, tighten all screws to 80%;
finally, tighten all screws to 100%
of the maximum torque.

2




First, tighten all screws to 80%;
finally, tighten all screws to 100%
of the maximum torque.


3



4




5



This is the front


6




This is behind

7



Remove from compression bag.



A




8





TIP: Align and attach the hook and loop fasteners for a secure connection

9




10

Remove from compression bag.




11


First, tighten all screws to 80%;
finally, tighten all screws to 100%
of the maximum torque.




12




13




14





15




16




After installation, the fabric wrinkles can be ironed.




Adjustable rotation with 4 levels left and right



Sitting posture




TV posture



Lying position

How to use remote control?



Note: When using the sofa for the first time, you need to successfully pair the remote control with the sofa, and then perform an initial reset on the sofa to ensure it functions properly.

1. Pairing function:

Pairing Mode: Within 30 seconds after the sofa is powered on, press and hold the “PAIR” for 10 seconds to enter the remote control's automatic pairing mode. The control box light will flash while waiting for pairing, and will turn off once pairing is successful.

Unpair: Press and hold both the “” and the “PAIR” for 10 seconds to enter the unpairing mode. The lights on the remote control panel will flash, indicating that unpairing is successful.

2. / Sofa posture control:

: Tap for single movement, long press for continuous movement, controls the sand art display.

: Tap for a short movement, long press for continuous movement, controls the sofa contraction.

: Tap for a small movement, long press for continuous movement, controls the elevation of the left armrest.

: Tap for a short move, press and hold for continuous movement, controls lowering the left armrest.

: Tap to move inch by inch, long press to continue moving, control the right armrest to raise.

: Tap for a short movement, long press for continuous movement, control the right armrest to lower.

3. Shortcut key:

: When pressed, the sofa moves to the sitting position, and the left and right armrests retract to the lowest position.

This position cannot be changed.

: After pressing, the sofa moves to the TV position; this position cannot be changed.

: Press to move the sofa to the lounging position; this position cannot be changed.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY !!!

How to use remote control?

4. Memory function:

Press the “**M1**”, When the corresponding backlight turns on, the sofa armrest will move to the posture set by the user, with the initial position being the “ SIT” position. Press and hold the “**M1**” and “**PAIR**” for 10 seconds. When the panel light on the remote control flashes, it indicates that the memory has been successfully saved, and the sofa will remember the current position.

5. Reset Function:

At the same time, press and hold the “ ” and “**PAIR**” buttons for 10 seconds, toggle the main control lever to reset. Once the reset is complete, the remote control panel lights will flash.

At the same time, press and hold the “ ” key and “**PAIR**” key for 10 seconds. The left armrest lever will reset, and once the reset is complete, the lights on the remote control panel will flash.

At the same time, press and hold the “ ” key and “**PAIR**” key for 10 seconds. The right armrest lever will reset, and once the reset is complete, the lights on the remote control panel will flash.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY !!!

WARRANTY

Furnimart Inc promises to repair or replace any Furnimart product or component that is found to be defective in material or workmanship within one(1) year from the date of original purchase so long as you, the original purchaser, still owns it. This is your sole and exclusive remedy. This warranty is subject to the provisions below.

Limitations:

- Upholstery on chairs is warranted for one year from date of purchase.
- Damage caused by the carrier in-transit is handled under separate terms.

Exclusions:

This warranty does not apply and no other warranty applies to:

- Normal wear and tear, which are to be expected over the course of ownership.
- Modifications or attachments to the product that are not approved by Furnimart Inc.
- Products that were not installed, used, or maintained in accordance with product instructions and warnings.
- Products used for rental purposes.

Seating Usage: To the extent that a seating product is used in a manner exceeding this, the applicable warranty period will be reduced in a pro-rata manner.

A word about color variations, fabrics and finishes:

Furnimart Inc does not warrant the color-fastness or matching of colors, grains, or textures of covering materials.

Safety and Care Advice

- A. Keep children and animals away from the assembly area. This furniture contains small parts that could cause choking if swallowed.
- B. Keep all plastic wrapping materials away from babies and children to avoid danger of suffocation.
- C. Ensure that all packaging is disposed of carefully and responsibly.
- D. From time to time check that there are no loose fittings on the unit, re-tighten when necessary.
- E. Two people may be required for the assembly of this product.
- F. Damaged components may influence the safety and function of a product. Never use the product if any component is missing or defective.
- G. Once items are part of fully assembled there are not returnable unless faulty.
- H. This item is only intended for indoor use and designed for use by one person at a time, the suggestion maximum static load capacity less than 250lbs.
- I. Some items will be supplied with a wall fixing strap, which we recommend is used to secure the item to the wall , to prevent a child from accidentally pulling furniture over.
- J. Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by in correctly installed or assembly furniture.
- K. Do not stand on the furniture or use it as a step stool or ladder as it may result in physical injury or damage to the product.
- L. Do not be expose this item to direct sunlight and never touch with sharp objects, which may cause damage to the product.
- M. Leather and Vinyl Coverings: Occasionally dust the leather or vinyl surface with a soft, clean cloth. For mild stains, combine water and a soft cloth. Wet the cloth and rub gently over the stain before wiping dry. For deeper stains, apply a mild soap to the cloth. Work into a lather and rub gently over the stain. Rinse with a damp cloth and wipe dry. Cleaning products may cause discoloration and should be tested in an inconspicuous location prior to use on the chair. Warranty does not cover adverse cleaning results or scratching or scuffing that occurs during normal use.
- N. Fabric Upholstery: Pay immediate attention to spills and vacuum regularly to maintain appearance. Cleaning products may cause discoloration and should be tested in an inconspicuous location prior to use on the furniure. This furniture should not be used for other than its intended purpose. Please regularly inspect this furniture for loose or missing screws, metal fatigue, cracks, broken welds, missing attachments and general instability. If this furniture is damaged or appears to be unstable or unsafe, immediately remove from service and replace or repair the item. Failure to follow these warning could result in serious injury.

FOLLOW US



 **Furnimart**TM

 12819 NE Airport Way,
Portland, OR 97230, USA

 818-471-3642

 info@furnimarts.com

 www.furnimarts.com