










Outdoor tent


Installation instruction




01 Please confirm the components before assembling.




02 Find the accessories below and assemble them according to the figure.




- 03** Locate the corresponding bracket tube and insert it into the bottom joint connector.




- 04** Install fittings on support tubes.



- 05** The fitting is connected to the corresponding part of tube No.1.





- 06** Find the top fitting and assemble as needed.





- 07** Find the fittings according to the drawings and assemble them.

※ It's connected through pipe number 3 and pipe 3-1.

The H can be used on both sides.



- 08** The wire mesh is 2 meters wide, first install the side and top, cover from right to left, and then cut the wire mesh with scissors, and install the remaining net on the other sides. Parts of single and double doors are not universal.



Tie the barbed wire to the iron pipe with tie M.