
Assembly Instructions



General Assembly Guidelines


I. Ensure that all parts and hardware are available before beginning assembly.

II. Follow each step carefully to ensure the proper assembly of this product.


III. Two people are recommended for ease in the assembly of this product.

IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.

V. A Phillips head screwdriver is required for the assembly of this product .




VI. Power tools should not be used to assemble this product.






VII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø1/4"x25mm	Bolt	14	pcs
B		Ø4x15mm	Screw	22	pcs
C		Ø1/4"x12mm	Bolt	5	pcs
D		Ø1/4"x12mm	Adjustable floor leveler	4	pcs
E			Bracket	1	pcs
F		Ø16	Washer	1	pcs
G		Ø4x30mm	Screw	1	pcs
H			Anchor	1	pcs
J		M4	Hex Key	1	pcs
K			Hook	3	set



Philips head screwdriver required for assembly
(not included)


The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.

Step 1




Using bolts (A) attach parts (1,9) into parts (2,4,6) with hex key (J) as per diagram.
Note: Do not fully tighten all the bolts .

Step 2




Using bolt (C) secure part (5), then using bolt (A) attach part (4) into part (3) with hex key (J) as per diagram. Fasten all the bolts .

Step 3




Using bolt (C) attach bracket (E) into part (2) with hex key (J) as per diagram.

Step 4




Screw out the bolt from hook then using bolt attach hook (K) into part (7) with Philips head screwdriver as per diagram .


Step 5



Secure screw (B) attach part (7) into parts (2,3,6) with Philips head screwdriver as per diagram.


Step 6






Secure screw (B) attach part (8) into part (1,7,9) with Philips head screwdriver as per diagram.

Step 7




Put and adjust the adjustable floor leveler as per diagram.
Position the assembled unit at the desired location .if necessary ,adjust the floor leveler at the bottom of the side frames to level the unit .

Step 8




WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.
Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



Put anchor (H) into the wall and then using screw (G) secure (F,E) into anchor (H) in the wall as per diagram .

Step 9



Final Assembly