ASSEMBLY INSTRUCTIONS 36INCH BATH VANITY (COMBO)



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"













IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Thank you for buying our products.

Please read the installation manual carefully before installation,

we need you to follow the instructions on the accessories and hardware

step by step assembly complete, our instructions are very detailed.

Products are environmentally friendly products,


Please rest assured that you do not soak in water, do not place very heavy items,

do not malicious push and pull,

if you have any problems in the process of assembly and use, please contact us.


Thank you again for your purchase of our products,

I wish you a happy life.





Part List - N725P246491 2 Side Panel (L) - 1pc Side Panel (R) - 1pc 3 4 Center Panel - 1pc Bottom Panel - 1pc 5 6 Back Panel Top - 1pc Back Panel Bottom - 1pc 7 8 Front Panel (L) - 1pc Front Panel (R) - 1pc 10 9 Bottom Rail - 1pc Door (L) - 1pc 11 12 **Drawer Front - 3pcs** Door (R) - 1pc 13 14 Drawer Back - 3pcs Drawer Side (L) - 3pcs


Part List - N725P246491





Hardware List - N725P246491















STEP: 8











X3






STEP: 12






HINGE ADJUSTMENTS



1 Sideways / Tilt adjustment


Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

