


Assembly Instruction Sheet for Model 517576

Package Contents

Part	Description	Quantity
A	Fixture Body	1 pc.
B	Hanging Chain	2 pcs.
C	Ceiling Canopy	1 pc.
D	Mounting Bracket	1 pc.



STEP 1

Thread the wire of Fixture Body(A) through the holes of the Hanging Chain(B).
Fix the Hanging Chain(B) to the Fixture Body(A).
Fix the other Hanging Chain(B) to the Fixture Body(A).

STEP 2

Install the Ceiling Canopy(C) to the Hanging Chain(B).

STEP 3

Remove the Mounting Bracket(D) from the Ceiling Canopy(C).
Mark the drilling position on ceiling with the help of the Mounting Bracket(D).
Drill holes on the marks and stick the expansion anchors into the holes.
Fix the Mounting Bracket(D) to the expansion anchors with self-tapping screws.

STEP 4

Hold the fixture close to ceiling.
Connect live line to wire color Black/Red from the Ceiling Canopy(C).
Connect neutral line to wire color White/Blue from the Ceiling Canopy(C).

STEP 5

Attach the Ceiling Canopy(C) to the Mounting Bracket(D).

STEP 6

Insert the bulb(not included) to the bulb base.

Your fixture is now assembled and ready to use.