



Important Guidelines for Your Ice Maker:

1. Connect to a drinking water supply
2. Maintain a minimum 59 in/15 cm space from all sides to walls
3. Keep the ice maker and power cord away from flammable materials
4. Avoid using cord extensions to prevent overheating and fire risks
5. Use the ice maker indoors; outdoor use is not recommended
6. Use only water, no other liquids, for ice production
7. The ice maker comes with a 66" power cord and three-prong plug
8. Upon arrival, keep the unit upright for 24 hours before initial use
9. Protect the ice maker from direct sunlight and heat sources like stoves or radiators
10. Ensure water pressure within 14.5-58 psi (0.1-0.4 MPa); use a changeover valve if needed
11. Connect the drain pipe before use, ensuring the outlet of the drainage pipe should be lower than the outlet of the ice maker
12. Note that ambient temperature affects ice-making times
13. Main unit (Ice Maker) offers water pump drainage and gravity drainage for the storage bin