

















Before You Start




- ⚠ Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.
- ⚠ Most of board parts are labeled or stamped on the raw edges. Have a check to make sure all parts are included.
- ⚠ Work in a spacious area, preferably on a carpet close to where the unit will be used.
- ⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.





A  Back frame (1 pc)	B  Left frame (1 pc)
C  Right frame (1 pc)	D  Bottom frame (1 pc)
E  Door frame (1 pc)	F  Middle frame (1 pc)
G  Top frame (1 pc)	1  Bolt 6x40 (22 pcs)
2  Bolt 6x20 (4 pcs)	3  Feet (4 pcs)
4  Allen key M4 (1 pc)	

STEP 1




Please don't fasten the screw completely during assembly process, It will be likely to lead to an assembling problem that screw hole position is not aligned. You can fasten completely when all parts have been assembled.






STEP 2






STEP 3




STEP 4



STEP 5



STEP 6



Done

Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting.

Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area.

Using solvents of any kind on your furniture may damage the finish.

Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care

Please protect your outdoor furniture with a cover when not in use since Long-term sunlight exposure will result in the damage on the surface.

In addition to sunlight damage, wood and metal frame suffers when exposed to extremes in temperature and humidity.

Proper care and cleaning at home will extend the life of your purchase.

Following these important and helpful tips will enhance your furniture as it ages.