






INSTALLATION DIAGRAM



| | | | |
|---|--|---|---|
|  |  |  |  |
| AA*2 | BB*2 | CC*2 | DD*2 |

EASY INSTALLATION

- STEP1** Fix the **CC** part on the **DD** part
- STEP2** Tighten the **BB** part on the **DD** part
- STEP3** Install the **AA** part

PRODUCT SPECIFICATIONS

Input:110-120V~,60Hz

AC outlets:600W

USING TIPS

Plug in the power first, then touch the base or metal of the lamp to turn on/off and adjust the 3 set of brightness.

TROUBLE SHOOTING

- 1.If your lamp does not work, please make sure that plug is firmly in and touch the base of the lamp to turn on.
- 2.If the lampshade is unstable, please screw the BB part which is fixed on the lamp holder.
- 3.If you have other questions, please feel free to contact us.

CUSTOMER SERVICE & WARRANTY

Thank you for your support and purchase of our products.
If you encounter any problem after receiving the goods or during the use of the products, please feel free to contact us on the Wayfair platform.

We have a professional customer service team to serve you.
Your email will receive a reply within 24 hours after it is sent.

Here's the way to contact us:

1. Log in your account
2. My Account --> click "Help & Contact"
3. Choose the specific item you want to communicate with us
4. Send your message or email
5. You will receive our reply within 24 hours

Note: Our products have a two-year warranty.

If the product cannot be used normally within the warranty, please contact us, we will do our best to give you a satisfactory answer.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

USER GUIDE

