




Care Label



Sharp Label



Suffocation Warning for Plastic Bags




Safety Warnings

6.00"

SAFETY WARNINGS:

- For outdoor use only.
- Fuels used in wood or charcoal burning appliances, and the products of combustion of such fuels, contain chemicals known to the state of California to cause cancer and birth defects or other reproductive harm.
- Outdoor fireplaces/pits are only to be used in well ventilated area a minimum of 20 ft from building walls, overhangs, trees, etc, to prevent fires or melting of materials from buildings.
- To avoid fire hazards never leave a burning outdoor fireplace unattended.
- Never use gasoline, kerosene, alcohol or other flammable fuel in or around the outdoor fireplace.
 - Do not use during windy conditions.
- Place outdoor fireplace on firm, level ground free of debris.
 - Do not use on wooden or composite decks.
- Keep children, pets, loose clothing and hair safely away from outdoor fireplaces. Failure to adhere to this could lead to severe personal injury or possible death. Do not allow children to use or play near this outdoor fireplaces.
- Please check with your local fire municipality or authority on any restrictions of use.



HARDWARE LABEL

