





Tractor Seat

Safety

- We recommend having at least one other person assist you with this assembly.
- This assembly includes pieces that are heavy, under tension, and may have sharp edges. Please use caution.
- If you feel the seat was not installed correctly or has malfunctioned, inspect the issue immediately. Do not drive your vehicle until you are confident that the seat is stable.
- Always use the appropriate safety equipment for your vehicle and your current project.
- Always follow workplace safety guidelines for operating heavy machinery.

Included Pieces

Seat backrest 	Left adjuster 	Retractable seat belt 	Nut (x4) 
Seat cushion 	Right adjuster 	Seat belt buckle 	Carriage Bolt (x4) 
	L Armrest 	R Armrest 	Hexagonal bolt x8(x4) (located on the side of the seat, please remove before use) 

- 1、The connecting plate is fixed to the base;
- 2、The connecting plate, handrail, is fixed to the backrest;
- 3、Pay attention the screws fixed tightening, you can use the seat.

