

## 3 Door Wardrobe ASSEMBLY INSTRUCTIONS



# IMPORTANT PLEASE READ BEFORE YOU CONTINUE FURTHER FOR DOMESTIC USE ONLY CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- We strongly recommend that you keep children away from your work area.
- Assemble this product as close to its final position as possible.
- Never drag or push products as this could cause damage to the joints making it inferior.
- Do not place this product next to a radiator or in direct sunlight.
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- · Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a duster, and do not use detergents of any kind. However, the surface will need to be retreated from time to time. This can be done by using block wax (unperfumed) and rubbing it over the whole item.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.



\*Use of power tools to assemble this product will invalidate any claim and could damage this product making it unsafe!!! \*Please assemble on a clean soft surface to avoid damage. \*Please check contents and read the instructions before commencing assembly.
\*Assemble this product following the enclosed instructions carefully.
\*Please take care to avoid damaging parts during assembly.

#### **PARTS LIST**


				1 / 11 VI C LIO I				
1	Right side panel	01	9	Back panel	02	17	Support block	01
2	Left side panel	01	10	Upper back panel strip	01	18	Centre panel	01
3	Right front upright	01	11	Bottom back panel strip	01	19	Centre front upright	01
4	Left front upright	01	12	Hanger support	02	20	Adjustable shelf	03
5	Top panel	01	13	Centre door	01	21	Large back panel	01
6	Hanging rail	01	14	Left door	01	22	Front crossbeam	01
7	Front crossbeam	01	15	Fixed shelf	01	23	Right door	01
8	Base	01	16	Door strip	01		1	'


#### **FITTINGS**


Α	Ø 8 x 30mm	49
В	(%) □□□□□□□□□□□ Ø 4,0 x 40mm	12
C	Ø 3,5 x 30mm	39
D	<b>≸)</b> Ø 3,0 x 16mm	65


	111111100	
E		06
F		03
G	M4 x 25mm	03
Н	Right	06


I	Left	03
J	0)——→ 10x10mm	70
K		12
L	0 1x 1x 1x	01











### **WARNING**

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

