

Fine Furniture for every stage of life

COMPUTER DESK

PAGE 1 OF 10

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 70 MINUTES

PARTS IDENTIFICATION

Α	LEG	2PCS
В	COMPUTER DESK LEG-RIGHT	1PC
С	COMPUTER DESK LEG-LEFT	1PC
D	KEYBOARD	1PC
E	ANGLE IRON RIGHT	1PC
F	ANGLE IRON LEFT	1PC
	PAGE 2 OF 10	

ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION

G	COMPUTER FRONT SUPPORT	1PC
Н	DESK FRONT SUPPORT	1PC
ſ	DESK BACK SUPPORT	1PC
J	BOTTOM SUPPORT	2PCS
К	COMPUTER BACK SUPPORT	1PC
L	TURNBUCKLE	4PCS
М	WIRE-LARGE	4PCS

N	WIRE	4PCS
0	CONNECT SUPPORT LARGE	1PC
Р	CONNECT SUPPORT	1PC
Q	SHELF CROSSBAR	4PCS
R	SHELF BOARD	1PC
S	BOTTOM SHELF CROSSBAR	2PCS
Т	TOP GLASS	2PCS

BOLT


(3/16" x 10mm BLK)

6


L	J FAN-SHAPED	GLASS					1PC
		HARD	WARE I	IDEI	NTIFICATION	1	
1	BOTTOM SUPPORT ALLEN-BOLT (1/4" x 50mm BLK)		4PCS	7	CONNECT BOLT (1/4" x 31mm BLK)		2PCS
2	ALLEN-BOLT LARGE (1/4" x 30mm BLK)	~ @	6PCS	8	SUCTION CUP (6mm)	Co.	15PCS
3	ALLEN-BOLT SMALL (1/4" x 15mm BLK)	™	24PCS	9	FLOOR LEVELER (1/4" x 30mm BLK)		2PCS
4	ALLEN-BOLT MEDIUM (1/4" x 22mm BLK)	\ @	1PC	10	HEXAGONALKEY (10.5mm)	ß	1PC
5	SCREW (4 x 12mm BLK)		4PCS	11	ALLEN WRENCH (4mm)		1PC

4PCS


STEP 1 Do not tighten until each step is completed or instructed.




STEP 2



STEP 3




STEP 4




PAGE 7 OF 10

STEP 5




STEP 6




PAGE 8 OF 10


STEP 7



STEP 8 COMPLETE







Note: Dimension tolerance ±5%