


# Assembly Instructions

**Caution :** You must read this before you proceed.

## **BARSTOOL**









**CAUTION :** This Barstool is NOT a TOY.



Keep your child / children at bay during the assembly process.

For moving the Barstool and to prevent damage to the Barstool two adults may be needed to execute this action.

## Parts List


NO.	Picture	Description	QTY
A		Chair Back	1
B		Chair Seat	1
C1		Left Front Leg (Labelled C1)	1
C2		Right Front Leg (Labelled C2)	1
D		Side Rail (The side with holes is the bottom side to face the floor after assembly)	2
E		Front Rail	1

## Hardware

①		Long Bolt (M8x75mm)	5
②		Short Bolt (M8x40mm)	7
③		Flat Washer	11
④		Screw (M4x50mm)	7
⑤		Spring Washer	11
⑥		Allen Key	1
⑦		Screwdriver	Not provided

## Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


## Assembly Steps

### OVERVIEW




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

## Step 1



Unpack and place all parts on a clean, non-marring surface.

## Step 2




Attach Front Rail (E) into the housing of the Left Front Leg(C1) and Right Front Leg(C2).

**2.1)** Secure the Front Rail (E) to Left Front Leg(C1) by using Screw (④) and Screwdriver (⑦).

**2.2)** Secure the Front Rail (E) to Right Front Leg(C2) by using Screw (④) and Screwdriver (⑦).

**Do not fully tighten Screws.**

### Step 3




Place the Chair Back(A) onto a flat, clean table, as shown above.

Attach Chair Seat(B) with wooden dowel to the housing of Chair Back(A)

Secure Chair Seat(B) to the Chair Back(A), using Short Bolt(②) Spring Washer(⑤) and Flat washer(③) with Allen Key(⑥).

**Do not fully tighten Bolts.**


### Step 4



Secure Chair Seat(B) to the Chair Back(A), using Long Bolt(①) Spring Washer(⑤) and Flat washer(③) with Allen Key(⑥).

**Do not fully tighten Bolts.**

## Step 5




Then, place the Chair onto the side of a table as shown in picture. You will have the chair bottom and legs facing skywards.

Attach the assembled frame from Step 2 into the assembled frame from Step 3 by using Short Bolt(②), Spring Washer(⑤) and Flat washer(③) with Allen Key(⑥).

**Do not fully tighten Bolts.**

## Step 6



Next place Side Rail(D) into the housing of the Hind Leg of the Chair Back(A) and Left Front Leg(C1).

You may need to apply a little pressure to the Legs - pushing outwards, so as to enable the Side Rail(D) to be slotted into position.


**6.1)** Secure the Side Rail(D) to Left Front Leg(C1) using Screw(④) and Screwdriver(⑦).

**6.2)** Secure the Side Rail(D) to Chair Back(A) using Screw(④) and Screwdriver(⑦).

**Do not fully tighten Screws.**

Repeat the same process for the other Side Rail(D) to Right Front Leg(C2).

### Step 7



Place the Chair right side up on a **LEVEL SURFACE** to see if it wobbles. If it wobbles, lift the Chair some 30cm to 50cm height from the ground. Keep your feet and toes well away from the drop zone.

Drop the Chair freely and vertically with all four legs, hitting the ground at the same time.

This Drop Test will help to ensure that all the Bolts, Screws and gaps reach full alignment status.

Test again for evenness on a **LEVEL SURFACE**.

If no wobbles are found, proceed to tighten all the Screws, and Bolts.

**When tightening these screws, tighten sequentially.**


**Do not tighten any Bolt, or Screw fully and then move towards the next one.**

**This could cause the frame to warp.**

**If there are still wobbles, loosen the Screws and Bolts and execute the same drop tests.**

**If the Chair is not stable it could lead to damage to the product.**

### Step 8























Inspect the Chair and make sure all parts are connected.

Your Chair is ready for use.

**This Chair can only be used on a flat, level surface.**

## Care & Maintenance

- |   |   |  |
|---|---|--|
|  |  | <input checked="" type="checkbox"/> Do not put hot items directly on furniture surface.                        |
|  |  | <input checked="" type="checkbox"/> Do not clean furniture with harsh cleansers or polish.                     |
|  |  | <input checked="" type="checkbox"/> Do not place furniture under direct sunlight.                              |
|  |  | <input checked="" type="checkbox"/> Do not place furniture near heating or cooling vents.                      |
|  |  | <input checked="" type="checkbox"/> Do not write on furniture without a padded barrier to protect the surface. |
|  |  | <input checked="" type="checkbox"/> Do not place furniture outside. For indoor use only.                       |
|  |  | <input checked="" type="checkbox"/> Not for commercial use. For residential use only.                          |
|  |  | <input checked="" type="checkbox"/> Stains may be removed with mild soap solution and damp cloth.              |
|  |  | <input checked="" type="checkbox"/> Children should not climb or jump on the furniture.                        |
- 
- |   |   |  |
|---|---|--|
|  |  | <input checked="" type="checkbox"/> Dust and pick-up spills using a clean, non-colored, lint-free cloth. |
|---|---|--|

### What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

### Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

### Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

### Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

