
















Children have died from furniture tipover. Fixed wall device have been included with this product;you must install the fixed wall device according to these instructions in order to minimize the risk of furniture.If you have any questions about this product or the Fixed wall device , please contact us immediately.











Never allow children to climb or hang on furniture,including drawers or cabiner doors.
In addition to installing the restrains,to help prevent tip-over.

1. Never put a TV or other heavy objects on top of this product.
2. Do not stand on the product.








1  759*400 1PCS	2  759*400 1PCS	3  610*400 1PCS	
4  610*400 1PCS	5  610*382 1PCS	6  362*391 1PCS	
7  362*321 1PCS	8  606*384 2PCS	9  620*400 1PCS	10  620*330 1PCS




Hardware installation demonstration

NOTE: Please make sure "A" hardware tightened and can't be pulled out!


I



II



III




IV




Scan QR code for assembly video


1




2



A*4



C*20



D*4






E*8

Put A on board ③④



Put C on board ③④⑤⑥⑦

3

**A*2****F*2****Put A on board ⑤**

**B*6****Put B on board ⑥⑦**




5




B*6

Put B on board ③④⑤

6

**B*6****E*16****Put B on board ③④⑤**






7



I*12



J*12



K*1

END

