


Assembly Manual

SWIVEL ROCKER RECLINER

A1257-2GSM-T



Please read this manual carefully before any operation and keep it properly for future use.

Customer Service: WefuyService@outlook.com

Edition: 20250503193Z

ASSEMBLY GUIDE

Congratulations, you now have a new functional sofa.

Before enjoy the comfort sofa, you have to put it together. This Assembly Guide will take you through the basic assembly process. To make sure your assembly goes smoothly, please follow the assembly instructions, **and especially the important safety information.**

Also, while it is possible to assemble the sofa on your own, **having a second person to help you makes it even easier.**

Before you begin, please check if there are any missing parts from the package. If you have any problems, please do not hesitate to send us an email and we will help you as soon as possible.


HOW TO GET SERVICE

E-mail "WefuyService@outlook.com" to submit your warranty claim.


Components List

30min

Assemble



One People




under the cushion


Compressed seat cushion (A) *1




Back (B) *1




Seat frame (C) *1



Arm frame (D)




Arm frame (E)




F(L) F(R)
under the cushion

Armrest Cover (F)



Massager remote control board (G) *1



Massager power supply (H) *1



Armrest pillar (M) *10


Components List




long screw (N) *10



Spanner (C) *1



Glove *1




Cup holder *2




spare



x2



Back ear





it's under the seat frame , pull the pull ring to open the rack and take it out

Assembly Instruction

Step 1

Use spanner O and screw N to pin through the inner iron frame D and the armrest pillar M to the outer frame E of the armrest. Tight all screws, please pay attention to distinguish the front and back of the armrest frame.




To facilitate packaging of products, we pre-installed the D(L) component on the rack. Please pull it out from the rack first and then assemble the handrail.

Step 2

Align the armrest cover to armrest-assembled iron frame in sequence of left and right, back and forward. so that the cloth cover hole is aligned with the insert hole. Pull the zipper after all is OK.



Front



Assembly Instruction

Step3


Repeat Step 1.



To facilitate packaging of products, we pre-installed the D(R) component on the rack. Please pull it out from the rack first and then assemble the handrail.

Step4


Repeat Step 2.



Assembly Instruction


Step 5

Install the armrest cup holder.



Step 6



Insert the arms into the seat in a way that they fit properly .
You will hear a click when they are securely engaged.



Assembly Instruction


Step 7

Pull the pull ring on the side of the seat and turn on the rack.



Step 8


Put the seat cushion to the corresponding position and stick the magic sticker to fixed seat cushion.



Assembly Instruction


Step9

Plug the back pad into the seat frame , then connect the massager lines: white with white , red with red , black with the power lines , connect the massage line with the hand controller.



Step10


Install the back ears on both sides of the backrest. Stick the velcro from the back frame to the seat frame.



Assembly Instruction


Step 11

Pull up the handle and spread out the sofa.



Step 12

Put away the sofa with your legs.



Done!


MASSAGE CHAIR

READ ALL INSTRUCTIONS

BEFORE USING THE ITEM

REMOTE CONTROL

Function of remote



I 、 Specifications of power adapter

Connect the adapter plug to the power cord socket of the center box, and then insert the adapter into the

220V output socket. Power adapter specifications:

Input: AC 100-240VAC, 50/60Hz; Output: DC12V, 1.5A.

II 、 Product features

- 1、 4 parts 8 motor vibration
- 2、 1 heating plate
- 3、 Supports USB charging 5V 2.0A
- 4、 3-segment timed shutdown duration selection
- 5、 Selection of 3rd gear vibration intensity
- 6、 5 vibration modes selection
- 7、 Default scheduled shutdown time 10Min

III、 Functiondetails

- 1 Vibration on key: Click to turn on the vibration function, then click again to turn off the vibration function (cycle);
- 2、 Vibration intensity key: Press and cycle to switch vibration intensity. When turned on, the default mode is M (middle), M → H → L (cycle);
- 3、 Timed shutdown button: Press and cycle to switch the timed shutdown time. The default time for powering on is 10 minutes; 10min → 20min → 30min (cycle);
- 4、 Heating on key: Click to turn on the heating function of the heating plate, and then click again to turn off the heating function of the heating plate (cycle);
- 5、 Vibration mode key: Click on cycle to switch vibration mode. The default mode for startup is M4 M4 → M5 → M1 → M2 → M3 (cycle);
- 6、 Vibration positioning key: Click to select the vibration location.