

Assembly Instructions

This lamp is partially assembled in the factory by qualified craftsmen. Some assembly is required before use. Please follow the assembly instructions carefully.

WARNING!-TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR PERSONAL INJURY:

- Turn off/unplug lamp and allow to cool before replacing bulb.
- Do not touch bulb when fixture is turned on.
- Do not look directly at lighted bulb.
- Keep materials that burn easily away from lighted bulb.

Assembly:

- 1) Pull the cord(A) from the bottom of lampbody(B), until the Neck (C) touched top of Lampbody (B);
- 2) Twist the Saddle & Neck (C) onto the top of Lampbody (B);
- 3) Put the Harp(D) into the Saddle & Neck (C);
- 4) Put the Shade(E) onto the Harp(D), then twist the Finial (F) to tighten the Shade(E).
- 5) Adjust the bottom of Shade(E) levelly.

Use only the bulb type and wattage indicated on the wattage label located near the socket.

WARNING:

Never exceed maximum wattage indicated, as it may cause fire.

Important Safety Instructions:

This portable lamp has a polarized plug(one blade is wider than the other)as a safety feature. This plug can be used in polarized outlets only one way. If the plug does not fit fully in the outlet,reverse the plug. If it still does not fit,contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

