

DIKE SWITCH

Many Lights

Link up to 6 (120V) / 16 (277V) fixtures.



01 Step 1
Open the access cover
to connect the wires.



02 Step 2
Connect additional fixtures
using the ground conductor.



03 Step 3
Secure the cover and tighten
the bracket.