

USE AND MAINTENANCE
- Use on level surfaces only
- Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly for safety.
- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

Glider Chair


Parts




A - Seat Base



B - Back Rest




C - Back (seated) Right



D - Back (seated) Left

Assembly Instructions

Step1



Step2

