



Read instructions before removing from box. NEVER lift arcade machine by its top!

This machine requires **two** people to properly take out of the box. Lift the machine up out of the box by the control panels. **Do not cut the machine out of the box.** If you notice damage to your machine it will have to be picked up by UPS in the original packaging. If you do not keep the original packaging, we will not be able to replace any item that may have become damaged during shipping.