


Power Motion Reclining Sofa

Assembly Manual

ME76019




CS.furniture@outlook.com

▲ CAUTION


THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.

COMPONENTS


BOX A - LAF




A




B



C




D




E

- A** LAF Chair
1X
- B** Plastic Leg
5X
- C** Plastic Washer
5X
- D** Power Cord
1X
- E** Adapter
1X

BOX B - Armless Chair



F




B




C

- F** Armless Chair
1X
- B** Plastic Leg
4X
- C** Plastic Washer
4X

BOX C - Wedge Chair



G




B




C

- G** Wedge Chair
1X
- B** Plastic Leg
5X
- C** Plastic Washer
5X

BOX D - RAF




H




B



C



D




E

- H** RAF Chair
1X
- B** Plastic Leg
5X
- C** Plastic Washer
5X
- D** Power Cord
1X
- E** Adapter
1X


BOX A : LAF

- 1 Locate the hardware pack and Adapter Box (marked with red nylon strip) from the bottom of the **LAF Chair** (A).




BOTTOM VIEW

- 2 Attach the **Plastic Leg** (B) with **Plastic Washer** (C) to the bottom of the **LAF Chair** (A) by turning clockwise.




- 3
 - 3.1 Connect one end of **Power Cord** (D) into the **Adapter** (E).
 - 3.2 Connect female head of the **Adapter** (E) into connection jack located at the bottom of the **LAF Chair** (A).
 - 3.3 Plug the other end of **Power Cord** (D) into the Power Outlet.

Note: After all the connections are made, the green LED of the adapter will be lit up.




4 Assembly completed.




BOX B : Armless chair

5 Locate the hardware pack (marked with red nylon strip) inside the hidden storage pouch.




BOTTOM VIEW

- 6** Attach the **Plastic Leg** (B) with **Plastic Washer** (C) to the bottom of the **Armless Chair** by turning clockwise.




- 7** The sofa headrest can be manually raised (lifted) by hand, but it can only be lowered after being lifted all the way up (to its full extent).




BOX C : Wedge Chair

- 8** Locate the hardware pack (marked with red nylon strip) inside the hidden storage pouch.




BOTTOM VIEW

- 9 Attach the **Plastic Legs** (B) with **Plastic Washers** (C) to the bottom of the **Wedge Chair** by turning clockwise.




BOTTOM VIEW

- 10 Assembly completed.




BOX D : RAF

- 11** Locate the hardware pack and Adapter Box (marked with red nylon strip) from the bottom of the **RAF Chair** (H).




BOTTOM VIEW


- 12** Attach the **Plastic Legs** (B) with **Plastic Washers** (C) to the bottom of the **RAF Chair** by turning clockwise.




- 13**
- 13.1 Connect one end of **Power Cord** (D) into the **Adapter** (E).
 - 13.2 Connect female head of the **Adapter** (E) into connection jack located at the bottom of the **RAF Chair** (H).
 - 13.3 Plug the other end of **Power Cord** (D) into the Power outlet.
- Note: After all the connections are made, the green LED of the adapter will be lit up.





14 Assembly completed.



15 Connect the chairs



- 16 Assembly completed. It's ready to use.



Design Exquisite Furniture For Your Home

PRODUCT WARRANTY

- 1-year limited on cover against splitting, peeling, and/or tearing.
- 1-year limited on internal and external frame structure.
- 1-year limited on cushioning material, seat springs and mechanism.

Contact us:

We make all efforts to guarantee that the products you receive are in excellent condition. If there are any parts missing or damaged, the Customer Service Team will be happy to provide free replacements for you. We have professional warehouses where the current inventory of parts is enough so that they will arrive in your hands as fast as possible.

Assistance with assembly or product details is available; don't hesitate to get in touch with us to get priority service.

Our E-mail address: CS.furniture@outlook.com.



CS.furniture@outlook.com