


# Simple Assembly Instructions

Do not use the tent in windy and rainy days, please fix the ropes and ground nails when using.



1		4 PCS		
①		4 PCS		
2		2 PCS		
②		2 PCS		
3		12PCS		
4		6 PCS		
5		6 PCS		
6		6 PCS		
7		2 PCS		
8		1 PCS		
A		4 PCS		6 PCS
B		2 PCS		12 PCS
C		2 PCS		
D		1 PCS		
E		6 PCS		
		1 PCS		
		4 PCS		
		2 PCS		

