
ASSEMBLY INSTRUCTIONS



Suggestion

- It is recommended to install it near a power source, as later steps will require the power to be turned on.
- This product requires installation by at least two people.

Conseil

- Il est recommandé de l'installer à proximité d'une source d'alimentation, car les étapes suivantes nécessitent la mise sous tension.
- L'installation de ce produit doit être réalisée par au moins deux personnes.

Hinweis

- Es wird empfohlen, das Gerät in der Nähe einer Stromquelle zu installieren, da für die nachfolgenden Schritte die Stromversorgung eingeschaltet werden muss.
- Für die Montage dieses Produkts werden mindestens zwei Personen benötigt。

Safety Information

Please read all instructions carefully before assembly.
Ensure all parts are properly installed and tightened before use.
Assemble the product on a flat and stable surface.
Keep small hardware parts away from children during assembly.
Do not use the product if any parts are damaged or missing.

Usage Warnings

Do not place excessive weight on the desktop or shelves.
Do not stand or sit on the product.
Use the product only for its intended purpose.
Avoid dragging heavy objects across the surface to prevent damage.

Child Safety Warning

This product is not a toy.
Keep children away from packaging materials and small components.
Children should not climb or play on the product.

Care Instructions

Clean with a soft, dry cloth.
Do not use abrasive cleaners or harsh chemicals.
Keep the product away from prolonged exposure to moisture.

Electrical Safety Warning

Use only the supplied power adapter.
Keep electrical components away from water.
Do not operate the product with wet hands.
Disconnect power before cleaning or maintenance.
Stop using the product if the power cord is damaged.

Sicherheitshinweise
Bitte lesen Sie alle Anweisungen vor der Montage sorgfältig durch.
Stellen Sie sicher, dass alle Teile vor der Verwendung ordnungsgemäß installiert und fest angezogen sind.
Montieren Sie das Produkt auf einer ebenen und stabilen Oberfläche.
Halten Sie Kleinteile und Befestigungsmaterial während der Montage von Kindern fern.
Verwenden Sie das Produkt nicht, wenn Teile beschädigt sind oder fehlen.

Warnhinweise zur Verwendung
Platzieren Sie keine übermäßig schweren Gegenstände auf der Tischplatte oder den Ablageflächen.
Stellen Sie sich nicht auf das Produkt und setzen Sie sich nicht darauf.
Verwenden Sie das Produkt nur für den vorgesehenen Zweck.
Ziehen Sie keine schweren Gegenstände über die Oberfläche, um Beschädigungen zu vermeiden.

Sicherheitshinweis für Kinder
Dieses Produkt ist kein Spielzeug.
Halten Sie Kinder von Verpackungsmaterialien und Kleinteilen fern.
Kinder dürfen nicht auf das Produkt klettern oder damit spielen.

Pflegehinweise
Reinigen Sie das Produkt mit einem weichen, trockenen Tuch.
Verwenden Sie keine scheuernden Reinigungsmittel oder aggressiven Chemikalien.
Halten Sie das Produkt von längerer Feuchtigkeitseinwirkung fern.

Elektrische Sicherheitshinweise
Verwenden Sie ausschließlich das mitgelieferte Netzteil.
Halten Sie elektrische Komponenten von Wasser fern.
Bedienen Sie das Produkt nicht mit nassen Händen.
Trennen Sie die Stromversorgung vor der Reinigung oder Wartung.
Verwenden Sie das Produkt nicht weiter, wenn das Netzkabel beschädigt ist.

Informations de sécurité
Veuillez lire attentivement toutes les instructions avant l'assemblage.

Assurez-vous que toutes les pièces sont correctement installées et bien serrées avant utilisation.
Assemblez le produit sur une surface plane et stable.
Gardez les petites pièces et les éléments de fixation hors de portée des enfants pendant l'assemblage.
N'utilisez pas le produit si des pièces sont endommagées ou manquantes.


Avertissements d'utilisation
Ne placez pas de poids excessif sur le plateau du bureau ou les étagères.
Ne montez pas et ne vous asseyez pas sur le produit.
Utilisez le produit uniquement pour l'usage auquel il est destiné.
Évitez de faire glisser des objets lourds sur la surface afin d'éviter tout dommage.

Avertissement de sécurité pour les enfants
Ce produit n'est pas un jouet.
Gardez les enfants éloignés des matériaux d'emballage et des petites pièces.
Les enfants ne doivent pas grimper sur le produit ni jouer avec celui-ci.

Instructions d'entretien
Nettoyez le produit avec un chiffon doux et sec.
N'utilisez pas de produits de nettoyage abrasifs ni de produits chimiques agressifs.
Évitez une exposition prolongée du produit à l'humidité.

Avertissement de sécurité électrique
Utilisez uniquement l'adaptateur secteur fourni.
Gardez les composants électriques à l'écart de l'eau.
N'utilisez pas le produit avec les mains mouillées.
Débranchez l'alimentation avant tout nettoyage ou entretien.
Cessez d'utiliser le produit si le cordon d'alimentation est endommagé.

PLEASE DO NOT RETURN TO THE STORE



If you have difficulty assembling this product, or if any parts aremissing or damaged, please contact the seller for assistance.


Please carefully review the following precautions before proceeding with the installation:

1.The installation process for this product is complex, and it is highly recommended to have at least two individuals working together during the installation.


2.Prior to each step, please refer to the screw hole positions to ensure that the board is aligned correctly according to the images provided in the instruction manual. This will help prevent any errors.

3.In case power tools are used for installation, it is important to tighten the screws intermittently rather than applying excessive force continuously. This precaution will help avoid potential cracks around the screw holes.


4.If you run into anyissues during assembly,please don't hesitate tocontact us.
Thank you for your attention to these important instructions.




















TWO-PERSON ASSEMBLY RECOMMENDED



ITISRECOMMENDED TOUSEPOWERTOOLS


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52



1 x 1
2 x 1
3 x 1
4 x 1
5 x 1
6 x 2
7 x 1
8 x 2
9 x 1
10 x 1
11 x 1
12 x 1
13 x 1
14 x 1
15 x 1
16 x 1
17 x 1
18 x 1
19 x 1
20 x 2
21 x 1
22 x 3
23 x 2
24 x 2
25 x 2
26 x 1
27 x 1
28 x 1
29 x 1
30 x 1
31 x 1

㉜ x 1  ㉝ x 1	㉞ x 1  ㉟ x 1	㊱ x 1 
㊲ x 2 	㊳ x 2 	㊴ x 2 
㊵ x 2 	㊶ x 1 	㊷ x 1 
㊸ x 1 	㊹ x 1 	㊺ x 1 
㊻ x 1 	㊼ x 2 	㊽ x 1 
㊾ x 2 	㊿ x 1 	(51) x 1 
(52) x 1 		

Hardware

A	x80
	
Cam Bolt	

B	x84
	
Cam	


C	x2
	
68mm Connector Bolt	

D	x26
	
⌀8*40mm	

E	x8
	
M3.5*45mm	

F	x8
	
Plastic End Cap	

G	x76
	
M3.5*14mm	

H	x4
	
⌀10*40mm	

I	x6
	
M3.5*30mm	

J	x16
	
M6*16mm	


K	x4
	
M8*100mm	

L	x8
	
⌀8	

M	x8
	
M8 Washer	

N	x8
	
M8 Nur	

O	x8
	
38mm Hole Cover	

P	x1
	

Q	x1
	

R	x8
	

S	x8
	


T	x8
	

U	x8
	

V	x6
	
Half-overlay hinge	

W	x2
	
Hinge without a lid	


X	x4
	
L350mm	

Y	x2
	
Y1 Y2	

Z	x2
	
Black Lifting lug	

AA	x4
	
M6*30mm	

AB	x1
	

AC	x1
	

AD	x1
	

AE	x12
	
M6*30mm	

AF	x1
	
M8*16mm	


AG	x4
	
ϕ5*20mm	

AH	x2
	
⌀5*410mm	

AI	x2
	
M8	

AJ	x14
	
M6*10mm	

STEP1




A	x4
Cam Bolt	


B	x4
Cam	

F	x4
Plastic End Cap	

E	x4
M3.5*45mm	

STEP2






X2	x2
L350mm	

G	x4
⌀3.5*14mm	

STEP3



AH	x2
⌀5*410mm	


A	x4
Cam Bolt	

B	x4
Cam	

F	x4
Plastic End Cap	

E	x4
M3.5*45mm	


STEP4




X2	x2
L350mm	


G	x4
⌀3.5*14mm	


STEP5




A	x14
	
Cam Bolt	

STEP6







B	x6
	
Cam	


D	x4
	
⌀8*40mm	


STEP7




A	x14
	
Cam Bolt	

STEP8







B	x6
	
Cam	

D	x4
	
⌀8*40mm	

STEP9







B	x8
Cam	

D	x12
⌀8*40mm	

STEP10





C	x2
68mm Connector Bolt	

R	x4

S	x4


T	x4


A	x10
Cam Bolt	

B	x4
Cam	

D	x2
⌀8*40mm	

STEP11






B	x10
Cam	

U	x4

STEP12



R	x4

S	x4


T	x4


A	x2
Cam Bolt	

B	x2
Cam	

U	x4

STEP13







A	x12
Cam Bolt	

B	x12
Cam	


STEP14






B	x8
Cam	

STEP15







A	x20
Cam Bolt	

B	x12
Cam	


STEP16





B	x8
Cam	

STEP17




D	x4
⌀8*40mm	

I	x6
M3.5*30mm	

STEP18

Make sure the accessory nuts face outward during installation.




AE	x4
M6*30mm	

G	x4
M3.5*14mm	

AB	x1

STEP19





G	x8
M3.5*14mm	

W	x2
Hinge without a lid	

V	x2
Half-overlay hinge	


STEP20





G	x16
M3.5*14mm	


STEP21




G	x8
M3.5*14mm	

V	x4
Half-overlay hinge	


STEP22






G	x16
M3.5*14mm	

STEP23



AA	x4
	
M6*30mm	


STEP24




X1	x4
	
L350mm	

G	x12
	
M3.5*14mm	

STEP25



STEP26





AE	x4
M6*30mm	

AB	x1

STEP27

Attention, please! Lift accessory 41 andaccessory 42 up by hand to the same level tofacilitate the installation of accessory 39 instep 28.






STEP28

First install the innerscrew, then installthe outer screw.

Note that the"gourd-shaped hole”here on the frontcrossbeam is closeto the left cabinet




AJ	x4
	
M6*10mm	

AB	x1
	


STEP29

press the legs on bothsides to the lowest position.


If it is not pushed all the way tothe bottom, it may cause the productto have uneven legs, which can resultin an uneven tabletop.



STEP30




STEP31




AJ	x2
	
M6*10mm	

AB	x1

STEP32



STEP33




AI	x2
	
M8	


AB	x1
	

STEP34


Step1: Connect the controller ofthe lifting frame, namely accessory 43, to the plugs of the other twoaccessories 45 and 48, and thenturn on the power.
Step2: Press the downward buttonon the controller for 5 seconds- thehand controller will display "RST".Release the button, then hold downthe downward button again untilthe digital tube shows a number.Step3: Press and hold the "Rise"button, raise the lifting frame to acertain height, then turn off thepower and proceed to the nextinstallation step.



STEP35




STEP36



AJ	x4
	
M6*10mm	

AB	x1
	


STEP37



AE	x4
	
M6*30mm	

AB	x1
	


STEP38



AJ	x4
	
M6*10mm	

AB	x1
	

STEP39



H	x4
⌀10*40mm	

O	x8


M	x8

N	x8


K	x4

L	x8

AD	x1




STEP40



G	x2
M3.5*14mm	

STEP41




Attention, please! At this step,screw J cannot be locked yet.All 16 screws need to be lockedbefore tightening screw J uniformly.

J	x16
M6*16mm	

AB	x1


STEP42




Z	x2

Y	x2
Y1	Y2

STEP43






AG	x4
	
Φ5*20mm	


STEP44

This socket comes with two adhesive modules, which can be attached to both ends of the socket.



G	x2
	
M3.5*14mm	

Q	x1
	

P	x1
	

AF	x1
	
M8*16mm	