



Models/Modelos/Modèles

**562-▲MPU-DST**  
Series/Series/Seria  
**Lineax™**





**RP104340▲**  
Lever Handle  
Manija de palanca  
Poignée à levier


**RP101958▲**  
Bonnet Cap & Indicator  
Indicador y tapa del capó  
Capuchon et indicateur de capot



**RP101762**  
Cartridge & Bonnet Nut  
Cartucho y tuerca del bonete  
Cartouche et écrou de capot




**RP101630▲**  
Metal Push Pop-Up  
Ventana emergente de empuje de metal  
Pop-up Push en métal



**RP101632▲ (not included)**  
Metal Push Pop-Up Less Overflow  
Ventana emergente de emergente menos desbordamiento de metal  
Pop-up Push Moins de débordement en métal

**RP101953-1.2 (1.2 gpm)**  
**RP101953-1.0 (1.0 gpm)**  
**(not included)**  
**RP101953-0.5 (0.5 gpm)**  
**(not included)**  
Aerator & Wrench  
Aerador y llave  
Aérateur et clé




**RP104341▲**  
Escutcheon and Gasket  
Chapetón y Empaque  
Boîtier et Joint


**RP47029**  
Bracket  
Abrazadera  
Support



**RP47030**  
Nut & Wrench Assembly  
Ensamble de Tuerca y Llave  
Écrou et clé



**RP51243**  
Gaskets  
Empaques  
Joints



**RP101764**  
Nuts, Gaskets and Ferrules  
Tuercas, juntas y casquillos  
Écrous, joints et viroles

▲Specify Finish / Especificque el Acabado / Précisez le Fini