

Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance

	• Not for commercial use. For residential use only.
	• Do not put hot items directly on furniture surface.
	• Do not clean furniture with harsh cleansers or polish.
	• Do not place furniture under direct sunlight.
	• Do not place furniture near heating or cooling vents.
	• Do not write on furniture without a padded barrier to protect the surface.
	• Do not place furniture outside . For indoor use only.
	• Stains may be removed with mild soap solution and damp cloth.
	• Children should not climb or jump on the furniture.
	• Dust and pick-up spills using a clean, non-colored, lint-free cloth.


Please look in Corners of carton for hardware packs and Legs.

Assembly Instructions

Please look in the Table for Hardware packs and Legs

Coffee Table


Item No: N735P464675



Caution: This Coffee Table is NOT a TOY. Keep your child / children at bay during the assembly process. Whenever lifting or moving the Table and to prevent damage to the Table, two adults may be needed to execute these actions.

ASSEMBLY INSTRUCTION

ITEM NO. N735P464675




ASSEMBLY INSTRUCTION

ITEM NO. N735P464675


Part List

A




Top Frame = 1pc

B




Legs = 4pcs

C



Upper support Legs = 1pc


D



Lower Support Legs = 1pc


Hardware List

1



Bolt 1/4" x 70 = 8 pcs

2



Bolts 1/4" x 35 = 8pcs

3




Flat Washer $\varnothing 16 \times 1.5$ = 8pcs

4



Lock Washer $\varnothing 12 \times 1.5$ = 8 pcs

5



Flat head screw M4 x 45 = 4pcs

6




Allen Key = 1 pc




Screwdriver (Not included)


Assembly Preparation Before Beginning Assembly:




A Top Frame = 1pc







B Legs = 4pcs



C Upper support Legs = 1pc



D Lower Support Legs = 1pc



Screwdriver (Not included)

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps

Overview



FRONT FACING


This Coffee Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

ASSEMBLY INSTRUCTION

ITEM NO. N735P464675

Step 1 Place the all parts face up on a clean, flat surface to avoid scratches.

Attach the Lower leg support (C) and Upper Leg support (D) onto the underside of the tabletop (A) Using the Bolts (2) and Allen Key (6) to tighten securely.




Bolts 1/4" x 35	Allen Key K4
	
② x 8	⑥ x 1

ASSEMBLY INSTRUCTION

ITEM NO. N735P464675

Step 2 Attach the Legs (B) onto the leg support rails (C) and (D), aligning them with the tenon on the support rails. Using the Flat Head Screws (5) and a screwdriver (Not included) to tighten securely.




Flat head screw	Screwdriver
M4 x 45	
	
(5) x 4	(Not included)

ASSEMBLY INSTRUCTION

ITEM NO. N735P464675

Step 3 Now grab a friend and carefully rotate the unit so that it's facing up.

Next, lift the tabletop (with the laptop attached) by hand, then use Bolts (1) + Flat Washer (3) + Spring washer (4) + the Allen Key (6) to secure the four legs (B) to the tabletop frame



Step 4 Check for wobbles on a LEVEL surface.

Your Coffee Table is ready for use,

This Coffee Table can only be used on the flat, level surface

