






ASSEMBLY INSTRUCTIONS SHUFFLEBOARD TABLE 108

HARDWARE LIST

A	ALLEN WRENCH		1 PCS.
B	TABLE TOP		1 PC.
C	TABLE BASE		2 PCS.
D	WASHER 1/4"		16 PCS.
E	SCREW 1 1/4" BASE		8 PCS.
F	FIX PLATE		2 PC.
G	PUCK CARBONIZED BLACK		4 PCS.
H	CHIPS COUNTER BLACK		21 PCS.
I	CHIPS COUNTER NATURAL		21 PCS.
J	SCREW 1 1/4" TOP		8 PCS.

K	FIXING ROD		4 PCS.
L	OPPRESSOR		4 PCS.
M	COUNTER ROD		2 PCS.
N	PUCK NATURAL		4 PCS.




“HEAVY ITEM HANDLE WITH CARE

REQUIRES HEX SOCKET 7/16" (11MM) HEX SOCKET NOT INCLUDED


ASSEMBLY INSTRUCTIONS SHUFFLEBOARD TABLE 108


1


REMOVE THE FIX PLATE FROM THE GAME TOP



THIS PART INCLUDES 8 SCREWS AND 8 WASHERS









DET. A


“HEAVY ITEM HANDLE WITH CARE, CAREFULLY ASSEMBLE COMPONENTS TO AVOID DAMAGE”


**“HEAVY ITEM HANDLE WITH CARE,
CAREFULLY ASSEMBLE
COMPONENTS
TO AVOID DAMAGE”**


**REQUIRES HEX SOCKET 7/16"
(11MM)HEX SOCKET NOT INCLUDED**














ADJUST LEVELER FOR BALANCE

Adjusting Floor Levelers

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

Adjust the Floor Levelers

Check for Stability – Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.
Locate the Levelers – These are small adjustable feet found at the bottom corners of your furniture.
Adjust as Needed – Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.