

Joint must be placed on the bracket to ensure your pole has the proper strength needed.

