


# ASSEMBLY INSTRUCTIONS


---



## TOOLS REQUIRED



Screwdriver  
( Not included)



(Included)  
Allen Wrench



2 - People

## ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 25-12-05

---



## **CHECK BEFORE STARTING**

☐

### **Are you missing anything?**

Double-check all parts, hardware and accessories listed are all accounted for.

☐

### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

### **Should we send any replacements?**

Are there any irregularities or flaws in the parts? We can send replacements!

☐

### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



## Suitable Location

Assembling near the area of the intended location is highly recommended.



## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


# ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY  
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly  
and insert screws or bolts into  
their respective holes.



Turn clockwise to tighten and  
only tighten when step is  
completed or when instructed  
to do so.



Use the appropriate hand tools  
or power tools for assembly.  
Select steps, such as tightening  
screws and/or bolts, may require  
hand tools to avoid causing  
damage during assembly.



Save the instructions and store  
any supplied tools for later  
maintenance.




After two weeks, check and  
tighten any loose hardware and  
repeat again every six months  
thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**

# SIDE CHAIR




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




## PARTS

P1 - 2 PCS



CHAIR BACK

P2 - 2 PCS




CHAIR SEAT

P3 - 2 PCS



LEFT STRETCHER **L**

P4 - 2 PCS



RIGHT STRETCHER **R**

P5 - 2 PCS



FRONT LEG LEFT **L**

P6 - 2 PCS



FRONT LEG RIGHT **R**

## HARDWARE

H1 - 4 PCS



M6X35mm JCBC SCREW

H2 - 16 PCS



M6x70mm JCBC SCREW

H3 - 20 PCS



SPRING WASHER

H4 - 20 PCS



FLAT WASHER

H5 - 8 PCS



M4x38mm CSK SCREW

H6 - 1 PC




ALLEN KEY

H7 - 8 PCS




NAIL LEG




# ASSEMBLY INSTRUCTIONS

Please read instructions carefully

Remove all wrapping materials, staples and packing straps from the carton. Refer to Parts List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g carpet or rug) to prevent parts from being scratched.  
CAUTIONS: 1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.  
2) DO NOT OVER-TIGHTEN BOLTS AND NUTS .  
3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.

| Carton | Designation            | Part List                                                                                    | Hardware List                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------|------------------------|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|        | CHAIR BACK             |  P1 x 2pc   |  H1 x 4pc                                                                                                                                                                                                                                                                                                                                                                       |
|        | CHAIR SEAT             |  P2 x 2pc   | M6x35mm JCBC SCREW                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|        | LEFT STRETCHER<br>(L)  |  P3 x 2pc   |  H2 x 16pc                                                                                                                                                                                                                                                                                                                                                                      |
|        | RIGHT STRETCHER<br>(R) |  P4 x 2pc   | M6x70mm JCBC SCREW                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|        | FRONT LEG LEFT<br>(L)  |  P5 x 2pc   |  H3 x 20pc                                                                                                                                                                                                                                                                                                                                                                      |
|        | FRONT LEG RIGHT<br>(R) |  P6 x 2pc | SPRING WASHER                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|        |                        |                                                                                              |  H4 x 20pc<br>Flat Washer<br> H5 x 8pc<br>M4x38mm CSK SCREW<br> H6 x 1pc<br>Allen Key<br> H7 x 8pc<br>NAIL LEG |



COMPLETE ASSEMBLY

# ASSEMBLY INSTRUCTIONS


## SIDE CHAIR

### PARTS LIST (FOR 2 CHAIRS)

| NO. | COMPONENT           | QTY. |
|-----|---------------------|------|
| P1  | CHAIR BACK          | 2    |
| P2  | CHAIR SEAT          | 2    |
| P3  | LEFT STRETCHER (L)  | 2    |
| P4  | RIGHT STRETCHER (R) | 2    |
| P5  | FRONT LEG LEFT (L)  | 2    |
| P6  | FRONT LEG RIGHT (R) | 2    |

### HARDWARE LIST (FOR 2 CHAIRS)

| NO. | DESCRIPTION          | QTY. |
|-----|----------------------|------|
| H1  | JCBC SCREW M6 x 35MM | 4    |
| H2  | JCBC SCREW M6 x 70MM | 16   |
| H3  | SPRING WASHER        | 20   |
| H4  | FLAT WASHER          | 20   |
| H5  | M4x38mm CSK SCREW    | 8    |
| H6  | ALLEN KEY            | 1    |
| H7  | NAIL LEG             | 8    |




COMPLETE ASSEMBLY

### STEP 1

Assembly Chair Seat (P2) into the Chair Back (P1) by aligning Bolts(H1) fitted with Spring Washer (H3) & Flat Washer (H4) into both center pre-drilled holes . Use Allen Key (H6) to tighten the bolts.


|        |                                                                                     |           |
|--------|-------------------------------------------------------------------------------------|-----------|
| H1 x 2 |    | M6 x 35mm |
| H3 x 2 |  |           |
| H4 x 2 |  |           |



### STEP 2

Now, proceed to secure the inside corners by aligning two set of bolts, on each side of the chair seat to finish securing it to the Chair Back. See image below for corresponding hardware to use.

|        |                                                                                     |           |
|--------|-------------------------------------------------------------------------------------|-----------|
| H2 x 4 |  | M6 x 70mm |
| H3 x 4 |  |           |
| H4 x 4 |  |           |



Insert Left Stretcher (P3) and Right Stretcher (P4) into the designated hole on Back Leg Frame (P1)


# ASSEMBLY INSTRUCTIONS

## MODEL : SIDE CHAIR

### STEP 3

You should now install Right and Left Front Legs (P5 and P6) . Insert legs into designated holes to connect to each side stretcher previously installed. Then, secure each leg to the chair seat frame by aligning corresponding bolts on each sides see image below. Lightly tighten the bolts using Allen Key (H6) just to keep them in place .

|        |                                                                                   |
|--------|-----------------------------------------------------------------------------------|
| H2 x 4 |  |
| H3 x 4 |  |
| H4 x 4 |  |




**DO NOT FULLY TIGHTEN BOLTS AT THIS POINT AS ONE LAST STEP IS STILL PENIDNG**

### STEP 4

|           |                                                                                     |
|-----------|-------------------------------------------------------------------------------------|
| H5 x 4    |  |
| M4 x 38mm |                                                                                     |


Align Screw (H5) to fit all the stretchers. Tighten the screws by using a household screwdriver.



### STEP 5


|        |                                                                                       |
|--------|---------------------------------------------------------------------------------------|
| H7 x 4 |  |
|--------|---------------------------------------------------------------------------------------|

Tap the Nali Leg (H7) to each chair Leg.



### CARE AND MAINTENANCE

- SAFETY** - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.
- CLEANING** - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.
- FITTINGS** - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.



## ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



### Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

**This product is intended for RESIDENTIAL USE ONLY and not for commercial use .**

### CARE AND MAINTENANCE


**SAFETY** - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.

**CLEANING** - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

**FITTINGS** - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.

# ASSEMBLY INSTRUCTIONS

---



## TOOLS REQUIRED



Screwdriver  
( Not included)



(Included)  
Allen Wrench



2 - People

## ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION #25-12-05

---



## **CHECK BEFORE STARTING**

☐

### **Are you missing anything?**

Double-check all parts, hardware and accessories listed are all accounted for.

☐

### **Check out our Quick Tips!**

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

### **Should we send any replacements?**

Are there any irregularities or flaws in the parts? We can send replacements!

☐

### **Prep Time!**

Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



## Suitable Location

Assembling near the area of the intended location is highly recommended.



## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


# ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY  
RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly  
and insert screws or bolts into  
their respective holes.



Turn clockwise to tighten and  
only tighten when step is  
completed or when instructed  
to do so.



Use the appropriate hand tools  
or power tools for assembly.  
Select steps, such as tightening  
screws and/or bolts, may require  
hand tools to avoid causing  
damage during assembly.



Save the instructions and store  
any supplied tools for later  
maintenance.




After two weeks, check and  
tighten any loose hardware and  
repeat again every six months  
thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**

## ROUND DINING TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



### PARTS

P1 - 1PC




TABLE TOP

P2 - 1PC



PEDESTAL LEG A

P3 - 1PC



PEDESTAL LEG B

P4 - 1PC



MOUNTING PANEL

### HARDWARE

H1 - 12 PCS



M6 X 35MM JCBC SCREW

H2 - 12 PCS



SPRING WASHER

H3 - 4 PCS



FLAT WASHER

H4 - 4 PCS




LEG ADJUSTABLE GLIDE

H5 - 1 PCS



ALLEN KEY



# ASSEMBLY INSTRUCTIONS

## Packed in 1 carton


Please read instructions carefully


Remove all wrapping materials, staples and packing straps from the carton. Refer to Parts List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g carpet or rug) to prevent parts from being scratched.

CAUTIONS: 1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.

2) DO NOT OVER-TIGHTEN BOLTS AND NUTS .

3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.

| Carton | Designation    | Part List                                                                                    | Hardware List                                                                                          |
|--------|----------------|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
|        | Table Top      |  P1 x 1pc   |  H1 x 12 <b>pc</b>  |
|        | Pedestal Leg A |  P2 x 1pc   | M6x35 JCBC SCREW                                                                                       |
|        | Pedestal Leg B |  P3 x 1pc  | Spring Washer                                                                                          |
|        | MOUNTING PANEL |  P4 x 1pc |  H3 x 4 <b>pc</b> |
|        |                |                                                                                              |  H4 x 4 <b>pc</b> |
|        |                |                                                                                              | Leg Adjustable Glide                                                                                   |
|        |                |                                                                                              |  H5 x 1 <b>pc</b> |
|        |                |                                                                                              | Allen Key                                                                                              |




COMPLETE ASSEMBLY

# ASSEMBLY INSTRUCTIONS


## ROUND DINING TABLE

| PART LIST |                |     |
|-----------|----------------|-----|
| No        | Description    | Qty |
| P1        | TABLE TOP      | 1   |
| P2        | PEDESTAL LEG A | 1   |
| P3        | PEDESTAL LEG B | 1   |
| P4        | MOUNTING PANEL | 1   |

| HARDWARE LIST |                     |     |
|---------------|---------------------|-----|
| No            | Description         | Qty |
| H1            | M6 x 35mm JCBC BOLT | 12  |
| H2            | SPRING WASHER       | 12  |
| H3            | FLAT WASHER         | 4   |
| H4            | ADJUSTABLE LEG STUD | 4   |
| H5            | ALLEN KEY           | 1   |




### STEP 1



Detach the Mounting Panel (P4) from the Table Top (P1) before assembling the table .

### STEP 2


Assemble the Pedestal Legs



### STEP 3

Attach the Mounting Panel (P4) to the Pedestal Legs , next, align the Bolt (H1) together with Spring Washer (H2) . Tighten all the bolts using Allen Key (H5) .

|        |                                                                                     |           |
|--------|-------------------------------------------------------------------------------------|-----------|
| H1 x 8 |  | M6 x 35mm |
| H2 x 8 |  |           |




# ASSEMBLY INSTRUCTIONS

## ROUND DINING TABLE

### STEP 4

|        |                                                                                   |
|--------|-----------------------------------------------------------------------------------|
| H1 x 4 |  |
| H2 x 4 |  |
| H3 x 4 |  |

With the help of two adults, carefully turn the Table leg upside-down. Next, attach the table leg to the the Table Top (P1). Align the holes in the Mounting Panel (P4) with the holes in the Table Top. Secure them by aligning the Bolt (H1) that fitted with Spring Washer (H2) and Flat Washer (H3) . Tighten the bolts using the Allen Key (H5) .





### STEP 5

H4 x 4



H4




Carefully put the table upright by two or more adults people.



ADJUST THE LEVELERS TO LEVEL THE TABLE

### CARE AND MAINTENANCE

- SAFETY** - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.
- CLEANING** - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.
- FITTINGS** - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.



### ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



#### **Keep this handy!**

Please retain this instruction manual and any order-related information for future reference.



#### **Lift, don't drag!**

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

**This product is intended for RESIDENTIAL USE ONLY and not for commercial use .**

#### CARE AND MAINTENANCE

**SAFETY** - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.

**CLEANING** - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

**FITTINGS** - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.