



3




Model: _____

Lot No: _____

Date of Purchased: _____

ACCENT CHAIR




ADULT ASSEMBLY REQUIRED

If you are missing any parts or have any questions regarding assembly, do not return this item to the retailers store. Please call our toll-free customer service number and have this assembly manual open to the parts list ready to provide the model name, and part name or number.




PARTS AND HARDWARE

Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.




Allen Key
1x




Bolt
12x




Washer
12x




Rear Legs



Front Legs




Backrest
1x



Seat
1x

ASSEMBLY INSTRUCTIONS

1



2

