

## Dining Table and Bench Assembly Instructions

Our tabletops and bench tops do not come with pre-drilled holes so that you can place the legs where ever you'd like and it does not limit to any style of leg if you wanted to switch it out.

The tops are wood and all that's needed is to use wood screws to attach the base to the top by screwing through the underside of the top.

Make sure to use 1"-1.25" wood screws for assembly so that the screws do not go through the top and poke out.