

Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.




- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in the magic tape pouch for hardware packs and legs.

ACCENT CHAIR



Parts List

Label	Picture	Description	QTY
A		Chair Seat	1
B		Chair Back	1
C		Front Leg	2
D		Hind Leg	2

Assembly Preparation

Before Beginning Assembly:	   *2  *2
----------------------------	---



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Place the Chair Seat(A) on a soft surface to avoid any scratches or damages to the product. OPEN the Seat Base Cover of the Chair Seat(A), take out the front legs and hardware accessories.

Step 2




Install the Front LEG(C) and Hind Leg(D) to the bottom of Chair Seat(A) with Plastic Washer ,
tighted by turning the leg clockwise as shown.
Repeat this process with the other legs(C)&(D).

Step 3



With the help of your adult partner, slide the Tapered Connectors on the Chair Back(B) into the Tapered Connectors on the the Chair Seat(A) until locked as shown in the picture .

Step 4



Make sure all parts are connected and securely locked into position.
Your Chair is ready for use.
This Chair can only be used on a flat, level surface.