Changing Table



THIS PRODUCT IS NOT INTENDED FOR INSTITUTIONAL OR COMMERCIAL USE.

If you have any questions or missing parts, please contact us. DO NOT return product parts to the store where it was purchased before contacting our Customer Service.

△WARNING:

READ ALL WARNING & SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USE OF THIS PRODUCT. KEEP INSTRUCTIONS FOR FUTURE USE.

Storage: The product must be kept in a dry and clean area.

Care and Cleaning: Do not scratch or chip the finish. Do not use abrasive chemicals for cleaning. Clean with mild soap on a soft rag. Rinse and dry thoroughly. If you choose to refinish this furniture, be sure to use only a non-toxic finish specified for children's products.

△WARNING:

SUFFOCATION HAZARD – BABIES HAVE SUFFOCATED WHILE SLEEPING ON CHANGING PADS. CHANGING PADS ARE NOT DESIGNED FOR SAFE SLEEPING.

• NEVER ALLOW BABY TO SLEEP ON CHANGING PAD.

FALL HAZARD – CHILDREN HAVE SUFFERED SERIOUS INJURIES AFTER FALLING FROM CHANGING TABLES. FALLS CAN HAPPEN QUICKLY.

- STAY WITHIN ARMS' REACH OF YOUR CHILD.
- **NEVER** LEAVE THE CHILD UNATTENDED.
- KEEP THE CHILD IN VIEW WHILE CHILD IS ON THE CHANGING TABLE.
- CAN ONLY RETAIN CHILD WITH MAXIMUM WEIGHT UP TO 30 LBS.
- **DO NOT** USE CHANGING TABLE IF IT IS DAMAGED OR BROKEN.
- CHANGING PAD SIZE 34" x 17" x 1".

PARENT SHOULD ENSURE A SAFE ENVIRONMENT FOR THEIR CHILD BY CHECKING THE FURNITURE CAREFULLY BEFORE PLACING CHILD IN THE PRODUCT. PLEASE MAKE SURE EVERY COMPONENT IS PROPERLY AND SECURELY IN PLACE.

PERIODICALLY CHECK FOR LOOSE OR WORN PARTS, TIGHTEN, REPAIR, OR REPLACE AS NEEDED.

THIS PRODUCT IS FOR RESIDENTIAL USE ONLY. ANY INSTITUTIONAL USE IS STRICTLY PROHIBITED.

IMPORTANT SAFETY NOTICE


This or any changing table unit can tip or fall over for when not used for its intended purpose. This could potentially result in serious injury or death.

Keep your children and others safe by following these simple rules:

- Do not allow climbing on any changing table unit.
- Do not leave drawers open when not in use.
- Do not allow standing in drawers
- Do not allow hanging from drawers.
- Do not allow standing on top of changing table unit.
- Do not place heavy objects in drawers.
- Do not place heavy objects on top of the changing table unit which can be pulled down on top of your child.
- To avoid head injury, do not allow your child to play underneath open drawers.
- Child must be securely fastened to changing table when the unit is in use.
- Always monitor your child's activity when in the nursery.


DO NOT assemble changer if parts and hardware are defective or missing. Contact us for exchange or keep the original box for return authorization


~ Changer Assembly Parts




~ Changer Assembly Hardware

No	Item #	Fittings	Qty
1	Allen key 3/16"*1"	l l l l l l l l l l l l l l l l l l l	1pc
2	Bolt 1/4"*2-1/2"		14pcs
3	Bolt 1/4"*2-1/4"		10pcs
4	Barrel 1/4"*13 mm		25pcs
5	Dowel 8*30mm		19pcs
6	Screw F4*25mm		20pcs
7	Machine Screw 3/16"*1"		6pcs
8	Bolt 5/32"*18mm		4pcs
9	Knob	C	4pcs
10	Bolt 1/4"*1-3/4"		1pc






Please follow this Parts Diagram to make sure that all parts are assembled in the correct position.




U	Shelf Divider	(1 pc)	S	Shelf	(1 pc)
A1	Left side panel	(1 pc)	0	Back Shelf Rail	(1 pc)
B1	Right side panel	(1 pc)	Ρ	Front Drawer Rail	(3 pcs)
Q	Back Drawer Rail	(1 pc)	R1	Upper Back Panel	(1 pc)
Ν	Front Shelf Rail	(1 pc)	Т	Lower Back Panel	(1 pc)

Please follow this Parts Diagram to make sure that all parts are assembled in the correct position.

 \sim Changer Drawer




C	drawer front panels	(2 pcs)	G	drawer bottom panels	(2 pcs)
D	drawer left panels	(2 pcs)	V	Drawer support	(2 pcs)
E	drawer right panels	(2 pcs)	10	Knob	(4 pcs)
F	drawer back panels	(2 pcs)			




Step 1: Attach Drawer Left Side Panel (D) and Drawer Right Side Panel (E)to Drawer Back Panel (F) with 8 screws (#6)

Step 2: Slide Drawer Bottom Panel (G) into the grooves of the side panels.








10 pcs

6

Screw


Е




Step 5: Attach Knob (#9) to Drawer Front (C1) with Bolt (#8).

Step 6: Insert 8 Dowels (#5) into top and bottom holes on each end of both Top Front Panel (H) and Top Back Panel (I).


Attach 2 Top Side Panels (J) to Top Front Panel (H) and Top Back Panel (I) by using 4 Barrel Nuts (#4) of each corner of top panels before inserting 4 Bolts (#3). Warning labels must be UPRIGHT and facing INWARD. Tighten firmly with Allen key (#1).



Step 7: Attach Top Panel (K1) to assembled unit part (H) and part (I) and part (J) by using 4 Barrel Nuts (#4) of part (H) and part (I) and part (J) before inserting 6 Bolt (#3). Tighten fimly with Allen key (#1)




Step 8: Attach Upper Front Rail (I) (L) and Upper Back Rail (M) to Top Panel (K1) with 6 Machinescrews(#7). Make sure all crews are tightly secured.




Step 9: Insert 3 Dowels (#5) into top holes on each end of both Front Shelf Rail (N) and Drawer Front Rail (P).

Attach Front Shelf Rail (N1) and Drawer Front Rail (P) and Back Shelf Rail (O) and Drawer Back Rail (Q) to Right Side Panel (B1) by using 5 Barrel Nuts (#4) of each holes of side panels before inserting 5 Bolts (#2). Tighten firmly with Allen key (#1).




Step 10: Upper Back Panel (R), Shelf (S) and Lower Back Panel (T) into the grooves of the rails.




Step 11: Insert 3 Dowels (#5) into top holes on each end of both Front Shelf Rail (N1) and Drawer Front Rail (P).

Attach Left Side Panel (A1) to unit by using 5 Barrel Nuts (#4) on the underside of right side of all rails before inserting 5 Bolts (#2). Tighten firmly with Allen Key (#1).



Step 12: Insert Dowel (#5) into Shelf Divider (U).

Attach Shelf Divider to Upper Back Panel by using a Barrel Nut (#4) before inserting Bolt (#10). Tighten firmly with Allen key (#1).



5	Dowel	1 pc
10	Bolt	1 pc
4	Barrel	1 pc
1	Allen key	1 pc


Step 13: Insert 6 Dowels (#5) into Left Side Panel (A1) and Right Side Panel (B1) and Shelf Divider (U) before attaching changing table top to the unit. Secure changing table top by using Barrel Nuts (#4) before inserting Bolts (#2).

Tighten firmly with Allen key (#1).

1


Allen key

L




1 pc

Step 14: Slide the drawers inside the assembled unit.




Changing Table Complete.



Wall Safety Strap

• TOOLS NECESSARY: RUBBER MALLET, PHILLIPS SCREW DRIVER. WARNING: WHEN UPRIGHT, IT IS POSSIBLE THAT THE FURNITURE MAY TIP OVER. FOR YOUR CHILD'S SAFETY, PLEASE INSTALL THE SAFETY WALL STRAP BEHIND THE FURNITURE.

PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT AND KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE. IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US.



STEP 1: Make a mark near the top of the back side of the furniture (in the center toward the top frame of the furniture of where you would like to install the safety wall strap). Insert the short screw through the washer and through the safety wall strap. Install the screw into where the mark was made behind the furniture using a Phillips screw driver **STEP 2**: Locate a wall stud. With the back of the Wall Stud furniture against the wall, locate the middle of the top of the dresser and make a mark against the wall. Measure 5cm down from the mark and drill a 1/8" pilot hole through the wall stud and into the plaster wall. **CAUTION**: The changer unit must be centered on a wall stud as shown. If you are unsure of how to locate the wall stud, contact a professional contractor. **STEP 3**: Attach the wall strap to the wall stud using the long 1-1/2" screw and washer as shown. Wall Stud Make sure strap holds steady and complete installation. CAUTION: Do not attempt to screw into the plaster wall only. You must also screw into a wall stud.

We strive to ensure that our customers are receiving a quality piece of furniture. We want our customers to be satisfied with using our products for years to come. In the event that you need assistance or have any inquiries regarding our products, please feel free to contact us with the information below.

To request replacement parts, please send an email to our customer service with the following information and we will do our best to assist you.

Proof of Purchase*
Item Number of the Product or Identification Sticker**
Part Letter or Number of the Replacement Part
Quantity
Your Shipping Address
Description of Your Problem

Please also provide pictures of the issue whenever possible. This will help us understand and assist you with your problem.

*Acceptable Proof of Purchase includes, but not limited to, your Online Purchase Confirmation Email, a screenshot of the purchase history of the online retailer, or a receipt from your local store.

Our warranty extends only to the original purchaser and is non transferable. Warranty is valid only when the proof of purchase can be provided.

Please retain a copy of your purchase records for future inquires.

**All of our baby products come with an identification sticker. This is a white sticker that contains all the product information of the item.

For cribs, the identification sticker is generally located near the bottom of the crib's side rails, the toddler guardrail, or the stabilizer bar.

For changers, the identification sticker is located on the top panel of the changing unit.

Under no circumstances should you remove any warning labels from the product. These labels are meant to be permanent and removing them may damage the wood and void your warranty.

One year limited warranty

We want you to be satisfied with any product that bears our name or logo. We will provide promptly, at the request of the retailer, and without charge, any missing parts that have been reported, with proper description, within 7 days of the purchase of the products. Our warranty guarantees optimal workmanship and lack of significant defects. The product warranty lasts a year from the date of your purchase. Please keep the original receipt so that we may process your one year limited warranty request. This warranty only covers new units with original packaging. Ownership of the warranty is non-transferable. The warranty does not cover any used, second-hand,

or demo models. Our obligation under this warranty is to replace or repair the merchandise, at our option, free of charge. This warranty does not cover any damaged or defective parts that result from normal wear and tear, abuse, negligence, improper use or alteration to the finish design, and hardware. Specific rights issued by this warranty may vary from state to state. Some states do not allow limitations on how long implied warranties last. DO NOT return products to the store once a product is used, it cannot be resold and the materials and energy invested in the product would go to waste. In the event that we determine that a defect that may result from customer abuse or misuse, we will contact you with information about services and methods to prevent occurrences. We strongly recommend you register your product with our company by filling out registration and mailing it back to us. This ensures you are up-to-date with our products' maintenance and information.

This warranty does not cover damage caused by accident, misuse or any use other than as intended and described in this assembly sheet or damage resulting from failure to maintain and clean this product as specified in this assembly sheet. **This warranty applies only to the original purchaser of the product.**

CAUTION! Safety Tips for Use of Changers

Many older changers, including secondhand or second use changers, may not meet all current safety standards. For baby's safety, even if you are on a tight budget, you should not purchase a used changer at a garage sale or accept a hand-me-down that does not meet the most recent Federal and ASTM standards.