

THANK YOU!

Dear Valued Customer,

Thank you for choosing Easyroom. We hope this product brings comfort and lasting value to your home.

Your comments and feedback are important to us. Please keep the carton and packaging materials until the product is completely installed.

Before installation, inspect the bathtub and all included parts. If any parts are missing or the product appears damaged, do not proceed with installation until the issue has been resolved.

*Sincerely,
Easyroom Service Team*



Please read all instructions carefully before proceeding with installation.



Due to the complexity of the installation procedure, a professional plumber is required.

TABLE OF CONTENTS



1. Pre-installation Checklist	P3
2. Tools Required	P6
3. Installation Instructions	P7
4. Care & Maintenance	P14
5. Warranty	P16

PRE-INSTALLATION CHECKLIST

Before installing the Easyroom freestanding bathtub, perform a pre-installation check to help ensure a smooth and successful installation.



1. Inspect the bathtub

- Carefully remove the bathtub from its box or crate. Two people are required to lift it. Do not carry the bathtub by its panel.
- To avoid scratches or damage, place the bathtub on a soft blanket over the cardboard.
- Inspect the bathtub for damage before installation. Do not install a damaged bathtub.



2. Leak test of the bathtub

- Set the bathtub on two 4"X4" lumber pieces, in order to have access from the bottom of the bathtub.
- Put a tray beneath the bathtub. Check for any leaks around the drain and pipe. If a leakage occurs please disassemble the drain line, you can apply a plumbing silicone caulk to fix the leakage.



3. Measurement and Fit

- Measure the space where the freestanding bathtub will be installed to ensure it fits properly.
- Check the dimensions of the bathtub and compare them with the available space, including doorways and hallways for delivery and installation.

4. Floor Strength

- Ensure that the floor can support the weight of the bathtub when filled with water and occupants. Consider reinforcing the floor if necessary.

5. Plumbing Connections

- Check the existing plumbing connections to ensure they are compatible with the bathtub's drain and overflow assembly.
- Confirm the location of the drain and overflow openings on the bathtub align with the existing plumbing.

6. Accessibility

- Ensure there is enough space around the bathtub for installation and maintenance access.
- Check if there are any obstacles or obstructions that may hinder the installation process.

7. Leveling

- Verify that the installation area is level to prevent the bathtub from rocking or shifting.
- Use a level to check the floor and make adjustments if needed before installing the bathtub.

8. Drainage

- Check the drainage system to ensure it is clear and functioning properly. Clear any clogs or debris that may affect drainage before installing the bathtub.

9. Utilities

- Ensure that water supply lines and drainage pipes are accessible and properly connected for the bathtub installation.
- Consider the location of electrical outlets if the bathtub has built-in features that require power.

10. Installation Requirements

- Gather all necessary tools and materials needed for the installation process.

By conducting a thorough pre-installation check and addressing potential issues before work begins, you can help ensure a successful installation of your freestanding bathtub. If you encounter uncertainty during the pre-check, consult a licensed professional plumber before proceeding.

INSTALLATION INSTRUCTIONS

Installing a freestanding bathtub is a rewarding project that can enhance the aesthetic and functionality of your bathroom. Here is a general guide on how to install a freestanding bathtub:

TOOLS REQUIRED



Level



Soft Cloth or blanket



Tape Measure




Pencil



Construction
Adhesive



Hammer



Silicone caulk




Shims / Lumber




Knife



Plumbers putty



Adjustable wrench




Furring strips

INSTALLATION STEPS

STEP 1

Prepare the Installation Area


Ensure the floor is level and can support the weight of the bathtub and water. Measure the space to ensure the bathtub fits properly.



STEP 2

Position the Bathtub



Carefully position the freestanding bathtub in the desired location, ensuring it is level. Use shims if needed to stabilize the bathtub and ensure it is even.



STEP 3

Mark locations


- Use a pencil to mark the outline of the bathtub's exact installed location and the drain hole on the floor.
- Move the bathtub away so that the plumbing can be installed.







STEP 4

Adjust the bathtub feet level

- Turn the tub upside down and set it on the soft blanket, to prevent any scratching of the bathtub trim.





- Place a level across the bottom of the tub and adjust the tub feet leveler to touch the level. Then raise the leveler an additional $\frac{1}{8}$ " or $\frac{3}{16}$ " so that the weight of the tub, water, and user are fully supported by the feet adjuster and not the tub walls.



STEP 5

Measure & cut

Measure and cut the tail piece to the appropriate length to reach the trap adapter. When setting the tub drain, insert tail piece with 1-1/2" slip joint and rubber washer into the trap adapter and tighten properly.




STEP 6

Connect the Drain

- Flip the tub over and carefully set the tub into position with the tailpiece assembly to the waste vent and connect to the drain.

-Connect the drain pipe to the bathtub drain using the provided parts. Ensure the connections are tight and secure. Use a P-trap and tubing cutter to connect the drain to the existing plumbing.



STEP 7


Secure the Bathtub

Secure the bathtub to the floor if necessary. Some freestanding bathtubs have leveling feet or brackets that need to be anchored to the floor for stability.

STEP 8

Caulk the Seams

Apply silicone caulk along the edges of the bathtub where it meets the floor and walls to create a watertight seal. This will prevent water from seeping underneath the bathtub.




24 hours

STEP 9

Test the Tub

Fill the bathtub with water to check for any leaks or issues. Ensure the drain is working properly and that the bathtub is securely installed.



STEP 10

Finish and Clean Up

Trim any excess caulk and clean up any debris from the installation process. Wipe down the bathtub to remove any dirt or marks.

By following these steps and the manufacturer's specific instructions, you can successfully install a freestanding bathtub in your bathroom. If you are unsure about any part of the installation process, consider consulting a professional plumber for assistance.

CARE & MAINTENANCE

Caring for and maintaining your freestanding acrylic bathtub is essential to keep it looking great and functioning well for years to come. Here are some tips and guidelines for proper care and maintenance:

1.Rinse After Use: After each use, rinse the tub with warm water to remove soap scum, hair, and other residues. This helps prevent buildup and staining.

2.Wipe Down: Use a soft cloth or sponge to wipe down the surfaces of the tub after rinsing to eliminate any remaining moisture. This can help prevent mold and mildew.

Weekly Maintenance

3.Regular Cleaning: Use a non-abrasive cleaner formulated for your specific bathtub material (e.g., acrylic, fiberglass, porcelain). Avoid harsh chemical cleaners that can damage the surface.

4.Scrub Gently: With a soft-bristle brush or sponge, scrub the tub gently to remove soap scum and mineral deposits. Pay special attention to areas around the drain and faucet.

5.Check for Mold and Mildew: Inspect corners and crevices for signs of mildew or mold. If you notice any, use a mold cleaner or a mixture of water and vinegar to treat the area.

Monthly Maintenance

6.Inspect Seals and Caulking: Check the caulking around the tub, especially where it meets the walls and the floor. Look for cracks or gaps that might allow water to seep behind the tub. If you find any issues, reapply silicone caulk to create a watertight seal.

7.Drain Maintenance: Occasionally, check and clean the drain, removing any hair or debris that may have accumulated. You can also use a mixture of baking soda and vinegar to keep the drain clear. Pour it down the drain, wait a few minutes, then flush with hot water.

Seasonal Care

8.Deep Cleaning: Every few months, consider doing a deeper cleaning of the tub. You can use a mild bleach solution (following the manufacturer's guidelines) or a specialized bathtub cleaner.

9.Check for Wear and Tear: Periodically inspect your bathtub for any signs of chips, scratches, or fading. If you notice any damage, address it promptly to prevent further deterioration.

Additional Tips

- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as they can scratch or dull the surface of the bathtub.
- **Be Mindful of Bath Products:** Some bath oils and bubble baths can cause film buildup on the tub. Use products that are gentle and designed for use in bathtubs.
- **Temperature Changes:** Avoid drastic temperature changes, like pouring boiling water directly into a cold tub, as this can cause damage.

10.Avoid Scratches and Damage:

- Use a soft cloth or sponge when cleaning the bathtub to prevent scratches on the acrylic surface.
- Avoid using abrasive scrubbing pads, brushes, or harsh cleaning tools that can scratch or damage the acrylic material.
- Do not place sharp or heavy objects directly on the bathtub surface, as they can cause scratches or dents.

11.Preventing Stains:

- To prevent stains, avoid leaving soap, shampoo, or other bath products sitting on the bathtub surface for extended periods. Wipe up spills promptly.
- Use a bath mat or rug inside the tub to prevent scratches and to absorb excess water, which can cause water spots and stains.

12.Temperature and Chemicals:

- Do not use hot water above 120°F (49°C) when cleaning the bathtub, as excessive heat can damage the acrylic material.
- Avoid using harsh chemicals, bleach, ammonia, or abrasive cleaners on the acrylic surface, as they can cause discoloration and damage.

13.Maintenance:

- Inspect the bathtub regularly for any signs of damage, cracks, or leaks. Address any issues promptly to prevent further damage.
- Keep the bathtub well-ventilated to prevent mold and mildew growth. Wipe down the surface and walls of the bathtub after each use to remove excess moisture.

By following these care and maintenance tips, you can keep your acrylic bathtub looking clean, pristine, and in good condition for years to come. Proper care and regular maintenance will help extend the life of your bathtub and ensure a relaxing and enjoyable bathing experience.

LIMITED WARRANTY COVERAGE

1 YEAR LIMITED WARRANTY

Easyroom products are made with quality materials and workmanship. If a defect in materials or workmanship is identified during normal use within one year of delivery, Easyroom may provide replacement parts at no charge or, at its option, replace a product or part determined to be defective under normal installation, use, service, and maintenance. This warranty applies only to the original purchaser and proof of purchase may be required.

Easyroom may, at its option:

- (1) repair or replace the defective part(s) or product(s) at no charge;
- (2) issue a refund of the original purchase price when valid under the applicable return period; or
- (3) issue a credit toward the purchase of a new Easyroom product. Shipping or delivery charges may apply.

Easyroom recommends installation by a licensed professional plumber. Easyroom is not responsible for damage or product failure caused by improper installation, misuse, or failure to follow the installation and care instructions. Removal and installation costs are not covered.

This limited warranty does not apply to products subjected to accident, negligence, improper installation, abuse, misuse, or cleaners containing abrasives, alcohol, or other damaging solvents. Easyroom responsibility under this limited warranty is limited to the remedies described above.

LIMITATIONS AND EXCLUSIONS

This warranty does not cover negligence, misuse, abuse, improper installation, carelessness, accident, hard-water or mineral deposits, exposure to corrosive materials, misapplication, improper maintenance, alteration of the product, or failure to follow the care and installation instructions supplied with the product.

This warranty is void if the product is altered or if repairs are attempted by anyone other than an authorized service provider. The warranty does not extend to plumbing or components installed by dealers, installers, or other third parties. Easyroom is not liable for loss of use, inconvenience, or other incidental or consequential costs, expenses, or damages to the extent permitted by law. Some states do not allow certain exclusions or limitations.

RESPONSIBILITIES OF OTHERS

The installer or building contractor acting on behalf of the user is responsible for inspecting the unit before installation and confirming that it is free of visible defects or damage. If a problem is discovered, the unit should not be installed.

Damage occurring in transit is the responsibility of the carrier. The user or installer should open the crate and inspect the unit when it is delivered. Any shipping damage should be reported promptly to the seller and carrier, and freight claims should be filed without delay.

Easyroom is not responsible for labor charges or damage incurred during installation, repair, or replacement, nor for indirect, incidental, or consequential damages, losses, injuries, or costs relating to this product. Except as required by law, this limited warranty replaces other express or implied warranties to the extent permitted by applicable law.

DISCLAIMER

Except as expressly provided in this guide, no additional warranty or obligation, express or implied, oral or statutory, is made by Easyroom. No dealer or other person is authorized to make warranties or representations concerning Easyroom products beyond those stated in the applicable written warranty.

WARRANTY SERVICE

When requesting warranty service, please have the following information available:

- Copy of the original invoice or proof of purchase
- Date of installation
- Description and photographs of the defect
- Model number or model description

To request warranty service or replacement parts, contact the seller or retailer from whom the product was purchased. The appropriate remedy may include repair, replacement, refund, or credit, depending on the circumstances and applicable policy.

WARNING

Packaging or product components may contain sharp edges or other potentially hazardous pieces. Keep packaging materials and small parts away from children. Use appropriate protective equipment and follow safe handling practices during installation.

EASYROOM

INSTALLATION GUIDE

Please retain this guide for future reference.
For installation questions, consult a licensed professional
plumber.

ACRYLIC FREESTANDING BATHTUB