


High Back Comfort Chair incl. Seat & Back Cushion Assembly Instructions

Product size:
W62*D77*H95 cm



IMPORTANT, RETAIN FOR FUTURE REFERENCE
READ CAREFULLY

High Back Comfort Chair incl. Seat & Back Cushion Assembly Instructions

Before you start

This product doesn't need any assembly work.



Warnings

**IMPORTANT, RETAIN FOR FUTURE
REFERENCE
READ CAREFULLY**

See enclosed instructions for safety and care information.

Failure to follow the warnings could result in serious injury.

Handle heavy parts with care.

This product is intended for **Domestic Use** only.

This product should only be used on firm, level ground.

Ensure the product is always placed on level ground.

Furniture can be dangerous if used incorrectly or maintained poorly. Keep your furniture in a good condition at all times. No liability will be accepted for damage or injury caused by failure to follow the the care and maintenance guidelines.



Dos

Unwrap all packaging materials and place the components on suitable surface to prevent scratching your product.

We recommend the use of furniture covers to protect your product when not in use.

During bad weather or in winter months, the product should be stored in a cool, dry place. Before storage, ensure that the product is clean and dry.

To clean, wipe down with a sponge and warm soapy water and wipe with a clean, dry cloth.

This product is suitable for all year outdoor use, but we recommend that a furniture cover be used to add additional protection to your product when not in use.

PLEASE NOTE - All cushions should be stored indoors after use. The cushions are not waterproof.

To clean the chairs or sofa, a pressure washer or jet wash on a wide spray can be used at a minimum distance of 1m from the product. Do not aim this directly at the joints of the furniture. Alternatively it can simply be wiped down by hand with a damp sponge and a weak solution of soap and water.

The feet on our all-weather wicker products are made from recycled PE materials. We would however still recommend lifting the products to move the items instead of dragging them which may cause some damage to either the product or the area in which you choose to use them.



Don'ts

Never drag furniture when moving it, always lift it.

Never tilt the product during use.

Do not stand or climb onto the product.

Do not sit or lean onto the arms/rims of this product.

Never use scourers, abrasives or chemical cleaner.


Do not use this product as a ladder as this could lead to unbalance and overturning.

High Back Comfort Chair incl. Seat & Back Cushion Assembly Instructions

Use Instructions

Ensure the product is always placed on level ground.
We recommend that the cushions are stored indoors or under waterproof cover in wet weather.

Never tilt the product during use.
Ensure the product is always placed firmly
on the ground.



PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE