











Please check that all fittings are available and in good condition before assembly.
 If you have any questions, please contact us , we will solve your problem in the first time.

PARTS LIST

Ax1 	Bx1 	Cx4 	Dx1 	Ex4  M8x8mm
Fx4  M6x25mm	Gx2  M6x50mm	Hx2  M6x60mm	Ix1 	


ASSEMBLE INSTRUCTION

1




Make sure the screw holes on opposite legs are in one line.

2




Tighten the screws to 50%.

3




Tighten the screws to 50%.

4



Tighten the screws to 100%.

5



Tighten the screws to 100%.

6

