

CENTERLOK

Fast and simple so you don't waste time struggling with your tent in-stead of enjoying the day



EASY SETUP IN JUST 3 STEPS!

The central hub lets you lock and release all 4 legs with just one touch



STEP 1



STEP 2



STEP 3