





Please check that all fittings are available and in good condition before assembly.
If you have any questions, please contact us , we will solve your problem in the first time.


PARTS LIST

Ax1 	Bx1 	Cx1 	Dx1 	Ex4 
Fx1 	Gx8  M6x18mm	Hx5  M6x30mm	Ix4  M8x15mm	Jx1 


ASSEMBLE INSTRUCTION

1

Tighten the screws to 100%.




2




Make sure the screw holes on opposite legs are in one line.

3




Tighten the screws to 50%.

4




Tighten the screws to 50%.

5




Tighten the screws to 100%.

6



7



8

