

LATERAL FILE DRAWER REMOVAL



- OPEN DRAWER FULLY. (TOP LEFT)
- PUSH PLASTIC TAB ON BOTH SIDES OF THE DRAWER. (TOP RIGHT)
- LIFT UP DRAWER AND REMOVE. (BOTTOM LEFT)
- TO INSTALL, REVERSE THE STEPS.