

ASSEMBLY INSTRUCTIONS
36INCH BATH VANITY (COMBO)



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.
"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!!
We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Before Installation

Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly,and follow the assembly steps to assemble your newly purchased product correctly and efficently.

Cam Lock Assembly Instructions





Diagram A



Insert Cam Bolt into hole as shown in diagram A.





Diagram B



Make sure not to insert the Cam Bolt:
Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.







Diagram C




Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.



Connect the panels together.




Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.

















To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver.
**Do not use an automatic screwdriver as it may bend or break if too much power is imposed.*

Detail View - CABINET














Identifying the Hardware-Identify the hardware using the illustrations below.







Part List - N710P533490

1  Side Panel (L) - 1pc	2  Side Panel (R) - 1pc
3  Mid Panel (L) - 1pc	4  Mid Panel (R) - 1pc
5  Top Crossbar Front - 1pc	6  Top Panel Rear - 1pc
7  Mid Crossbar (L) - 1pc	8  Mid Crossbar (R) - 1pc
9  Drawer Fake - 1pc	10  Bottom Panel Rear - 1pc
11  Bottom Frame - 1pc	12  Cabinet Door (L) - 1pc
13  Cabinet Door (R) - 1pc	14  Top Drawer Face - 2pcs


Part List - N710P533490


15  Top Back Panel - 2pcs	16  Top Drawer Side Panel (L) - 2pcs
17  Top Drawer Side Panel (R) - 2pcs	18  Top Drawer Panel Bottom - 2pcs
19  Mid Drawer Face (A) - 1pc	20  Mid Drawer Back Panel (A) - 1pc
21  Mid Drawer Side Panel (L-A) - 1pc	22  Mid Drawer Side Panel (R-A) - 1pc
23  Mid Drawer Panel Bottom (A) - 1pc	24  Mid Drawer Face (B) - 1pc
25  Mid Drawer Back Panel (B) - 1pc	26  Mid Drawer Side Panel (L-B) - 1pc
27  Mid Drawer Side Panel (R-B) - 1pc	28  Mid Drawer Panel Bottom (B) - 1pc
29  Sink - 1pc	


Hardware List - N710P533490


A  ø6x35mm	B  ø14.5x12mm	C  ø13x1/4"x28mm
Three in one bolts(39pcs)	Three in one lock(39pcs)	Hex-Head bolts(10pcs)
D  ø1/4"x16x1mm	E 	F  ø7xø3.5x15mm
Washer(10pcs)	Damping hinge (4pcs)	Flat head screw (24pcs)
G 	H 	I  ø5/32"x15mm
Handle (6pcs)	Handle (2pcs)	Handle screw (12pcs)
J  ø5/32"x19mm	P 	Q ø7xø3.5x12mm
Handle screw (2pcs)	L-Bracket (2pcs)	Round head screw (4pcs)
R  ø8xø4x25mm	S  ø8xø4x32mm	T  ø8x30mm
Round head screw(4pcs)	Round head screw(16pcs)	Wood dowel(40pcs)
U  4mm	V 	
Allen key(1pc)	Anti fall hardware(2sets)	


STEP: 1













STEP: 2


C	D	T
4PCS	4PCS	2PCS



STEP: 3


P	Q	T
2PCS	4PCS	2PCS






STEP: 4


B	T
4PCS	2PCS







STEP: 5

B	T
4PCS	4PCS





STEP: 6

B	T	R
		
3PCS	2PCS	4PCS




STEP: 7


T

6PCS




STEP: 8


B	C	D
		
6PCS	3PCS	3PCS








STEP: 9


B	C	D	T
			
6PCS	3PCS	3PCS	6PCS






STEP: 10


G	I
	
1PC	2PCS



STEP: 11


E	F
	
4PCS	8PCS






STEP: 12


H	J	F
2PCS	2PCS	16PCS






STEP: 13

A
16PCS



STEP: 14


B	S	G	I	T
8PCS	8PCS	2PCS	4PCS	8PCS



x2


STEP: 15

B	S	G	I	T
4PCS	4PCS	1PC	2PCS	4PCS




STEP: 16


B	S	G	I	T
4PCS	4PCS	2PCS	4PCS	4PCS




STEP: 17




STEP: 18






STEP: 19

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.

STEP: 20






HINGE ADJUSTMENTS




1 Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from the side of the cabinet
anticlockwise to move the door closer to the side of the cabinet



2 4 Height adjustment

While supporting the weight of the door, turn the screws
clockwise to move the door up
anticlockwise to move the door down



3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw
clockwise to decrease the gap between the door and the cabinet
anticlockwise to increase the gap between the door and the cabinet

