














PARTS*QTY

ASSEMBLY INSTRUCTIONS


Ax1 	Hx5 
Bx1 	Ix10  M6x10mm
Cx2 	Jx4  M6x20mm
Dx1 	Kx2  M6x35mm
Ex1 	Lx4  M8x35mm
Gx1 	Mx1 



How to assemble the armrest?

Step 1

Attach and screw the armrests to the backrest.



Step 2

Adjust the backrest by hand if necessary to align the screw holes of the seat cushion and armrest. Then screw the armrest to the seat cushion.

