





Product Assembling Instructions

Parts List:

NO.	Part	Qty	Image
①	Chair Back	3	
③	Seat Panel	3	
⑤	Cushion	3	
Ⓑ	Screw(6x30mm)	21	


NO.	Part	Qty	Image
②	Right Arm Rest	3	
④	Left Arm Rest	3	
Ⓐ	Screw(6x35mm)	6	
Ⓔ	Allen Wrench	1	

CHAIR x 3PCS




Step 1

Secure chair back (1) with seat panel (3) by using screws(6x30mm) and Allen Wrench (E). Please do not fully tighten the screws during this step.




Step 2

Secure right arm rest (2) to assembled chair back(1) by using screws(6x30mm), screws(6x35mm),and Allen Wrench (E). Please do not fully tighten the screws during this step.




Step 3

Secure left arm rest (4) to assembled chair back (1) by using screws(6x30mm), screws(6x35mm), and Allen Wrench (E). Please verify the alignment and adjust, then fully tighten all the screws this in step.




Step 4


Put cushions (5) on the chair. Single seat chair is assembled.




Product Assembling Instructions

PARTS LIST

1		1pc
3		4pcs


2		1pc
---	---	-----

HARDWARE LIST

A	X4
	
$\phi 10 \times 645\text{mm}$	

B	X4
	
M10	

C	X4
	
M10	

D	X4
	





E	X1
	


TABLE x 1PC




Step 1



Step 2



Step 3



Warning: Our products can be used between 14 degrees to 122 degrees. If used for more than 12 hours outside this temperature range, the rattan will harden or break.