Assembly Instructions

CAUTION : You must read these Assembly Instruction before you proceed


SAFETY WARNING

Never adjust chaise lounge or recliner backrest while seated.

Always make sure the backrest is flat before moving the chaise lounge.

Keep all limbs clear from under the backrest when it is in a raised position.

Serious finger, hand, or other bodily injuries may result from adjusting the chaise lounge backrest position while seated.




The examples pictured above are non exhaustive and are for your reference only

Care & Maintenance

- Not for commercial use. For residential use only.
- Do not put hot items directly on furniture surface.
- Do not clean furniture with harsh cleansers or polish.
- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
- Stains may be removed with mild soap solution and damp cloth.
- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look into the Seat Panel for hardware packs.









LOUNGE CHAISE





CAUTION: This Lounge Chaise is NOT a TOY

Keep your child / children at bay during the assembly process.
For turning the Lounge Chaise and to prevent damage to the Lounge Chaise, two adults may be needed to execute this action.


Parts List

Label	Picture	Description	Qty
A		Left backrest rail	1
B		Right backrest rail	1
C		Back rail	1
D		Front rail	1
E		Backrest Panel	1
F		Backrest support	1
G		Seat Panel	1
H		Leg	4

Parts List


Label	Picture	Description	Qty
I		Stretcher	2
K		Support leg	2
L		Cushion	1

Hardware:

No.	Picture	Description	Q.ty
①		Screw (M6x60mm)	5
②		Bolt (M6x50mm)	3
③		Bolt (M6x35mm)	24
④		Washer (6x18x2mm)	3
⑤		Washer (6x18x5mm)	3
⑥		Allen wrench	2

Assembly Preparation:


Before Begining Assembly:




- Read instructions, cover to cover
- Have 2 adults on hand for assembly
- Do not assemble on the flooring or carpet
- Assemble on a clean, non-marring surface (packing foam)
- Save all packaging until finished.

Assembly Steps:


Overview:






This Lounge Chaise has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Lounge Chaise parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise the parts and steps before assembly.

Step 1:




Unpack and place all the parts on a clean, non-marring surface.

Step 2:




Fix the Back rail (C) and Font rail (D) to the Left backrest rail (A) using 2pcs Bolts (③) and the Allen wrench (⑥).
DO NOT fully tighten the bolts.

Step 3:




Fix the Right Backrest Rail (B) to the Back Rail (C) and Font Rail (D) using 2pcs Bolts (③) and the Allen Wrench (⑥).
DO NOT fully tighten the bolts.

Step 4:



Fix the Backrest support (F) to the Backrest panel (E) using 2pcs Bolts (②) ,2pcs Washers (④) and the Allen wrench (⑥).
DO NOT fully tighten the Bolts.

Step 5:




Step 5.1

Step 5.2


Step 5.1 : Insert the assembled Step 4 into the assembled Step 3 .
Step 5.2 : Then adjust the backrest (E) to a straight position aligned with the assembled Step 3 . As shown above picture .

Step 6:




Fix the Step 3 assembled to the Step 4 assembled using 2 pcs Bolts (③), 2 pcs Washers (⑤) and the Allen Wrench (⑥).
Do not fully tighten the Bolts.

Step 7:




Fix the Step 5 assembled to the Seat panel using 4 pcs Bolts (③) and the Allen wrench (⑥).
Do not fully tighten the Bolts.

Step 8:




Fix the 2 Leg (H) to the Stretcher (I) using 2pcs Screws (①) and the Allen wrench (⑥).
Fully tighten the Screws.


Step 9:



Step 9.1 : Fix the assembled Step 7 to the assembled Step 6 using 8 pcs Bolts (③) and the Allen wrench (⑥).
Step 9.2 : Fix the 2 Support leg (K) to the assembled Step 6 using 4pcs Bolts (③) and the Allen wrench (⑥).
DO NOT fully tighten the Bolts.


Step 10:





With the help of your adult partner, Turn over Lounge Chaise. Place the Cushion (L) on the Lounge Chaise .Then affix the Magic Tape Straps as shown above.

Step 11:



Inspect it and make sure all parts are adequately connected.
Gently and gracefully, sit onto the Lounge Chaise. This will help to align all the parts at all joint areas.
Then get off the Lounge Chaise and in a sequential manner, gradually tighten all Screws at all joints until evenly connected.
If there are still wobbles, loosen the Screws and execute this same process.
WARNING!! IF LOUNGE CHAISE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.
Your Lounge Chaise is ready for use.
This Lounge Chaise can only be used on a flat, level surface.