



20 : 00

estimated
assembly time



2 or more

people required

Ok, let's
get started!



- Put on mood music!
- To prevent damage to product, use the clean side of package carton or rug as working surface.
- In the event of missing or damaged parts, delivery problems etc., please reach out to our team.
We will be happy to fix the problem!

care guide

- Clean regularly with a soft and dry cloth.
- To protect finish, avoid use of abrasive cleaners.
- Wipe up spills immediately. Please!



product parts



(A)
Table Top
x1



(B)
Table legs
x4

what's included




(C)- Plain Washer
(16X8mm)
x16



(D)- Lock Washer
(8.5mm)
X16



(E)- Bolt
(6 x 16mm)
x16



(F)- Allen Key
x1

YS Yellow sticker

GS Green sticker

RS Red sticker

WS White sticker

assembly instructions


Friendly Tip: Take a deep breath going in. This may be a tricky part, but nothing too overwhelming. Just follow these steps to the T and the outcome will be worth it!



- ⓘ While assembling the product, tighten the bolts up to 50%. Once all parts are in place, only then fully tighten the bolts.


step 1:

Start by placing the table top (A) upside down on a flat surface. Now, align the legs (B) with the slots given in the table top (A). Ensure the stickers on the leg are similar to the stickers on the table top.




step 2:

Fix the leg to the top by using plain washer (C), lock washer (D) & bolt (E) in the given slots. Tighten them using an allen key (F).



step 3:

Repeat step 2 with the remaining legs.





Voila! Your end table is now assembled and secure!

you've
got
a home
with us