

Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.




- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in Chair for hardware packs and legs.




Sets often ship in multiple boxes and may arrive a day or two apart.

SIDE CHAIR


N771P474921



PART LIST


Label	Picture	Description	QTY
A		Front legs	2
B		Back legs	2
C		Seat Frame With Cushion	1
D		Back Frame	1

Hardware

Label	Picture	Description	QTY
1		Bolts (M6x60MM)	8+1
2		Bolts (M6x40MM)	4+1
3		Spring Washer (Ø1/4*10MM)	12+1
4		Flat Washer(Ø1/4"x13MM)	4+1
5		Flat Washer(Ø1/4"x16MM)	8+1
6		Allen key (4MM)	1
7		Wooden Plugs (Ø16x7MM)	4+1
8		ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)	1

Assembly Preparation

Before
Beginning
Assembly:



	① x 8+1
	② x 4+1
	③ x 12+1
	④ x 4+1
	⑤ x 8+1
	⑥ x 1
	⑦ x 4



- Read instruction, cover to cover.



- Have 2 adults on hand for assembly.



- Do not assemble on flooring or carpet.




- Assemble on a clean non-marring surface (packing foam).



- Save all packaging until finished.


Assembly Steps

Overview



This Side chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Side chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.


STEP 1



	① x 8+1
	② x 4+1
	③ x 12+1
	④ x 4+1
	⑤ x 8+1
	⑥ x 1
	⑦ x 4


Unpack and place all parts on a clean, non-marring surface.

STEP: 2




Assemble Seat Frame With Cushion (C) to Back legs (B) using bolts (1). Spring Washer (3) Flat washer (5) Allenkey (6) **Note: Do not fully tighten the bolts at this step.**

STEP: 3




Attach the assembly from Step 2 to Front legs (A) using bolts (1). Spring Washer (3) Flat washer (5) Allenkey (6) **Note: Do not fully tighten the bolts at this step.**

STEP: 4



Assemble Back Frame (D) to the assembly from Step 3 using bolts (2). Spring Washer (3) Flat washer (4) Allenkey (6) **Note: Do not fully tighten the bolts at this step.**

STEP: 5



Place the Chair on a Level Surface to check for wobbles.


If it wobbles, lift the Chair some 30 to 50 cm high from the ground, keep your feet and toes well away from the drop zone, and drop the Chair vertically with all four Legs, hitting the ground at the same time. The Drop Test will help to ensure that all Bolts and gaps reach full alignment.

Test again for evenness on a Level Surface.

If no wobbles are found, proceed to tighten all the Bolts.


When tightening the Bolts, tighten sequentially. Do not tighten any Bolt fully and then move on to the next one, this could cause the frame to warp. If it still wobbles, loosen the Bolts and execute this same drop test. If the Chair is not Stable it could lead to damage to the product.

STEP: 6



Close the Wooden Plugs (7) tightly to the previous bolt catch hole

STEP: 7



Your Chair is ready for use.