







Please read these instructions and warranty information carefully before use and keep them properly for future reference.

OPERATING INSTRUCTIONS

Part List

A		2
B		2
C		2
D1		1
D2		1
E		1
F		1

G	 M6*25	4
H	 M6*35	1
I	 M6*40	14
J	 M6*48	2
K	 M6*52	2
L		14
M		10
N		1
I		1

Assembly Instructions

