


# ASSEMBLY INSTRUCTIONS

## DINING TABLE




### NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten the screws or bolts, as this may damage the product.
- Please ensure you retain all the product packaging until the item is completely assembled.
- Periodically check all fitting and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.


## PARTS IDENTIFICATION

1- Table Top



1 pc

2- Table Legs



4 pcs


## HARDWARE IDENTIFICATION

A- Allen Key M5




1 pc

B- JCBB Bolt M8 x 60mm




8 pcs

C- Spring Washer 5/16" x 15mm



8 pcs

D- Flat Washer 21/64" x 18mm



8 pcs

NOTE: Quantities shown are for one table.  
Bolts are metric screw threads

